



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		45516	PLATE, TRANSOM	1		
1		48290	PLATE, TRANSOM	1	(IDENTIFICATION: "INDICATOR :	
1		49701A 2	PLATE ASSEMBLY, TRANSOM	1	(IDENTIFICATION: "INDICATOR :	
2	16	47360	STUD, SHIFT CABLE TO TRANS	1		
3	23	31866	SPACER, SHIFT CABLE STUD	1		
4	12	39143	WASHER, SHIFT CABLE STUD	2		
5	11	20361	NUT, SHIFT CABLE STUD	1		
6	54	22740	CLIP, SWITCH LEADS TO TRANS	1		
6	54	24836	CLIP, SWITCH LEADS TO TRANS	1		
6	54	23568	CLIP, SWITCH LEADS TO TRANS	2		
7	10	35519	SCREW, SWITCH LEADS CLIP TC	1		
7	10	21643	SCREW, SWITCH LEADS CLIP TC	1		
8		22789	"D" WASHER, SWITCH LEADS C	2		
9	37	39395	DECAL, SERIAL NUMBER	1		
10		46004	LEVER, SHIFT CONTROL - TRAN	1		
10		45529	LEVER, SHIFT CONTROL - CAM L	1	SEE PAGE 15 FOR BREAKDOWN!	
10		49702A 2	LEVER, ASSEMBLY, SHIFT CONT	1	SEE PAGE 15 FOR BREAKDOWN!	
11	16	47360	STUD, SHIFT CABLE TO LEVER	1	SEE PAGE 15 FOR BREAKDOWN!	
12	23	31866	SPACER, SHIFT CABLE STUD F	1	SEE PAGE 15 FOR BREAKDOWN!	
13	12	39143	WASHER, SHIFT CABLE STUD	2	SEE PAGE 15 FOR BREAKDOWN!	
14	11	20361	NUT, SHIFT CABLE STUD POW	1	SEE PAGE 15 FOR BREAKDOWN!	
15	10	22659	SCREW, SHIFT CABLE ASSEMBL	1	NOT USED WITH POWER TRIM	
16	23	31866	SPACER, SHIFT CABLE ASSEMBL	1	NOT USED WITH POWER TRIM	
17	12	39143	WASHER, SHIFT CABLE ASSEMB	2	NOT USED WITH POWER TRIM	
18	11	20361	NUT, SHIFT CABLE ASSEMBLY TC	1	NOT USED WITH POWER TRIM	
19	16	34069	STUD, SHIFT ACTUATING CABLE	1		
20	12	39143	WASHER, SHIFT ACTUATING CA	3		
21	11	20361	NUT, SHIFT ACTUATING CABLE	2		
22	23	46003	SPACER, SHIFT CONTROL LEVER	1	NOT USED WITH POWER TRIM	
23	13	38376	STUD, SHIFT CONTROL LEVER	1	NOT USED WITH POWER TRIM	
24	12	26825	WASHER, SHFIT CONTROL LEVE	2	NOT USED WITH POWER TRIM	
25	11	21528	NUT, SHIFT CONTROL LEVER TC	1	NOT USED WITH POWER TRIM	
26		45517A 2	ARM ASSEMBLY, SWITCH ACTU	1		
27	23	45600	SLEEVE, SWITCH ACTUATING	1		
28	24	45599	SPRING, TENSION - SWITCH A	1		
29	10	33231	SCREW, TENSION SPRING TO	1		
30	12	26825	WASHER, TENION SPRING SCI	1		
31	18	32857	COTTER PIN, SHIFT ACUTUATI	1		
32	16	32467	STUD, SWITCH ACCTUATING ARM	1		
33	23	37981	SPACER, SWITCH ACTUATING A	1		
34	12	26825	WASHER, SWITCH ACTUATING	2		