



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	57020	FUEL LINE, INLET - FUEL TANK T	1		
2		58514	FUEL PUMP ASSEMBLY	1		
3		58542	REPAIR KIT, FUEL PUMP	1		
4	10	46629	SCREW, FUEL PUMP CLAMPIN	6		
5		58585	CAP, FUEL PUMP FILTER	1		
6	10	58567	SCREW, FILTER CAP ATTACH	2		
7	12	46643	WASHER, FILTER CAP SCREW	2		
8		58592	ROD, FUEL PUMP ACTUATING	1		
9	53	58591	SNAP RING, PUMP ROD	1		
10		58590	SPACER, FUEL PUMP	1		
11	27	58589	GASKET, FUEL PUMP TO CYLIND	2		
12	16	46522	STUD, FUEL PUMP TO CYLIND	2		
13	12	58588	WASHER, FUEL PUMP STUD	2		
14	12	58587	WASHER, FUEL PUMP STUD	2		
15	11	58586	NUT, FUEL PUMP STUD	2		
16	22	38214	ELBOW, FUEL PUMP OUTLET	1		
17	32	56729	FUEL LINE, FUEL PUMP TO CAR	1		
18	32	56219	PIPE, CHOKE - CARBURETOR TC	1		
19		56511	COVER, CHOKE PIPE	1		
20	11	21310	NUT, COMPRESSION - CHOKE PI	1		
21	54	56510	CLIP, CHOKE PIPE TO EXHAUST	1		
22	10	49309	SCREW, CHOKE PIPE CLIP TO E	1		
23	13	26996	LOCKWASHER, CHOKE PIPE CLIP	1		
24	54	56406	CLIP, CHOKE PIPE TO INTAKE M	1		
25	10	20031	SCREW, CHOKE PIPE CLIP TO IN	1		
26	13	26992	LOCKWASHER, CHOKE PIPE CLIP	1		
27	22	58153	FITTING, CARBURETOR FUEL IN	1		
28	1351	4263A 1	CARBURETOR ASSEMBLY	1	SEE E4 FOR BREAKDOWN SER	
28	1351	4263A 2	CARBURETOR ASSEMBLY	1	SEE E4 FOR BREAKDOWN SER	
29	10	24644	SCREW, FLAME ARRESTOR TC	1	SERIAL 00000000-03225967	
29	10	20784	SCREW, FLAME ARRESTOR TC	1	SERIAL 03225968-09999999	
30		52734	BALL, MOUNTING - FLAME ARF	1		
31	23	35555	SPACER, FLAME ARRESTOR S	1	SERIAL 00000000-03225967	
31	23	61343	SPACER, FLAME ARRESTOR S	1	SERIAL 03225968-09999999	
32	12	20533	WASHER, FLAME ARRESTOR S	1		
33	11	28941	NUT, JAM - FLAME ARRESTOR	1		
34		56732	FLAME ARRESTOR, CARBURETOR	1	SERIAL 00000000-03225967	
34		61314	FLAME ARRESTOR, CARBURETOR	1	SERIAL 03225968-09999999	
35	12	22937	WASHER, FLAME ARRESTOR SC	1		
36	11	20586	NUT, FLAME ARRESTOR SCREW	1		
37	22	56506	HOSE, VENT - FLAME ARRESTOR	1	SERIAL 00000000-03225967	