



NOTE:
 For Continuity Circuit Components, see
 page 3.

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1547	815930A	DRIVE SHAFT HOUSING ASSEM	1		
2	10	79953	SCREW	1		
3	12	19183	WASHER (FIBER)	1		2
3	25	805726	O-RING (RUBBER)	OPT		2
4	24	17997A	1 SPRING KIT (RUBBER)	1		
5	26	66302	OIL SEAL	1	(Serial No. 0M400411 and Below)	
5	26	864319	OIL SEAL	1	(Serial No. 0M400412 and Up)	2
5A		821564	PLUG	1		
6		814386	WEAR PAD (PORT)	1		
6		814387	WEAR PAD (STARBOARD)	1		
7	19	32297	PLUG	1		
8		59830A	5 UNIVERSAL JOINT	1	(COUPLING YOKE HAS 2 O-RING	
9		46020T	YOKE, GEAR END	1	(COUPLING YOKE HAS 2 O-RING	
10		39383T	SOCKET, CENTER	1	(COUPLING YOKE HAS 2 O-RING	
11		75832A	3 CROSS AND BEARING	2	(COUPLING YOKE HAS 2 O-RING	
12		59830A	7 YOKE, COUPLING END	1	(COUPLING YOKE HAS 2 O-RING	
13	25	25439	O-RING	2	(COUPLING YOKE HAS 2 O-RING	2
8		814819A	2 UNIVERSAL JOINT	1	(COUPLING YOKE HAS 3 O-RING	
9		46020T	YOKE, GEAR END	1	(COUPLING YOKE HAS 3 O-RING	
10		39383T	SOCKET, CENTER	1	(COUPLING YOKE HAS 3 O-RING	
11		805536A	1 CROSS AND BEARING	2	(COUPLING YOKE HAS 3 O-RING	
12		814819A	3 YOKE, COUPLING END	1	(COUPLING YOKE HAS 3 O-RING	
13	25	25439	O-RING (.862 I.D.)	2	(COUPLING YOKE HAS 3 O-RING	2
13	25	35027	O-RING (1.046 I.D.)	1		2
14		816811	1 RETAINER	1		
15		35983	RING	1		
16	25	70937	O-RING	1		2
17		66081A	2 CARRIER ASSEMBLY	1		
18	26	823894	OIL SEAL	1		2
19	31	35988A	12 ROLLER BEARING KIT	1		
20	23	35985	CUP SPACER	1		
21	15	35980A	1 SHIM	AR		3
22	15	71013	SHIM	1		
23	43	55778A	3 GEAR KIT (2.40 RATIO)	AR	(20-24 GEAR RATIO)	3
23	43	55778A	3 GEAR KIT (1.98 RATIO)	AR	(20-24 GEAR RATIO)	3
23	43	45814A	5 GEAR KIT (1.65 RATIO)	AR	(24-24 GEAR RATIO)	3
23	43	75325A	3 GEAR KIT (1.84 RATIO)	AR	(17-19 GEAR RATIO)	3
23	43	18411A	2 GEAR KIT (1.50 RATIO)	AR	(20-22 GEAR RATIO)	3
24	31	35990A	1 ROLLER BEARING	1		
24	31	32573A	1 ROLLER BEARING (1.50 RATIO O	1		
25	12	46910	1 WASHER	1		