



NOTE: FOR CONTINUITY CIRCUIT COMPONENTS, SEE THE "CONTINUITY KIT" SECTION.

7496

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1547	861063A 4	DRIVESHAFT HOUSING ASSEMB	1		
2	10	79953A 2	SCREW KIT, (.375-16 x .250), D	1		
3	12	19183	WASHER, Fiber	1		17
4	24	17997A 1	SPRING KIT	1		
5	26	66302	SEAL, Oil	2	SN# 0M400410 & Below	15,18
5	26	864319	SEAL, Oil	1	SN# 0M400412 & Up	17
6		821564	PLUG	1		
7		814386	WEAR PAD	1	(PORT)	
7		814387	WEAR PAD	1	(STARBOARD)	
8	19	824928	PLUG, Rubber	1		
9		814819A 7	UNIVERSAL JOINT	1	SN# 0M400411 & Below	
9		864281A 2	UNIVERSAL JOINT	1	SN# 0M400412 & Up	
10		853635	YOKE, Gear End	1	SN# 0M400411 & Below	
10		865492T	YOKE, Gear End	1	SN# 0M400412 & Up	
11		39383T	SOCKET, Center, Center	1	SN# 0M400411 & Below	
11		865503T	SOCKET, Center	1	SN# 0M400412 & Up	
12		805536A 2	CROSS AND BEARING	2	SN# 0M400411 & Below	
12		865493A01	CROSS AND BEARING	2	SN# 0M400412 & Up	
13		814819A 3	YOKE, Coupler End, Coupler End	1	SN# 0M400411 & Below	
13		865491A01	YOKE, Coupler End	1	SN# 0M400412 & Up	
14	25	29845	O-RING, (.924 x .103)	2		17
14	25	35027	O-RING, (1.046)	1		17
15		816811 1	RETAINER	1		
16		35983	RING	1		
17	25	70937	O-RING	1		17
18		66081A 2	CARRIER ASSEMBLY	1		
19	26	823894	SEAL, Oil	1		17
20	31	30894A 5	BEARING KIT, Roller	1		
21	23	853649	SPACER, Bearing Cup	1		
22	15	35980A 1	SHIM SET	AR		
23	15	71013	SHIM, Spacer	1		
24	43	853641A 2	GEAR KIT, (20-22 GEARS)	1	(1.47:1 RATIO)	
24	43	853640A 2	GEAR KIT, (24-24 GEARS)	1	(1.62:1 AND 2.00:1 RATIO)	
24	43	853643A 2	GEAR KIT, (17-19 GEARS)	1	(1.81:1 RATIO)	
24	43	853642A 2	GEAR KIT, (20-24 GEARS)	1	(1.94:1 AND 2.40:1 RATIO)	
25	31	35990A 1	BEARING ASSEMBLY, Roller	1		
25	31	32573A 1	BEARING ASSEMBLY, Roller	1	(1.47:1 RATIO ONLY)	
26	12	45810	WASHER	1		
27	11	22339	NUT, (.625-18)	1		
28	15	36178A 1	SHIM SET	AR		
28	15	88297A 1	DRIVESHAFT HOUSING SEAL KIT	1		