



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1568	3388A 1	DRIVE SHAFT HOUSING ASSEM	1		
2	16	46311	STUD, DRIVE SHAFT HOUSING	4		
3	16	27879	STUD, DRIVE SHAFT HOUSING	2		
4	11	22178	NUT, DRIVE SHAFT HOUSING S1	4		
5	11	23161	NUT, DRIVE SHAFT HOUSING S1	2		
6		52107	PLATE, HEAT SHIELD	1		
7		48921A 1	SHIFT DETENT ASSEMBLY	1		
8	10	21091	SCREW, SHIFT DETENT TO DRIN	2		
9	11	20361	NUT, SHIFT DETENT SCREW	2		
10	12	20086	WASHER, POWERHEAD STUDS	8		
11	11	20509	NUT, POWERHEAD STUDS (3/8-	2		
11	11	23161	NUT, POWERHEAD STUDS (3/8-	6		
12	11	21528	NUT, POWERHEAD STUDS (5/16	2		
13	32	48905	TUBE, WATER INLET	1		
14		37417	COVER, TRIM - DRIVE SHAFT HC	1		
15	10	37571	SCREW, TRIM COVER TO BOTTC	4		
16		37919	SEAL, TRIM COVER TO DRIVE S1	1		
17		37665	STRIP, RETAINING - TRIM COVEI	2		
18	10	48409	SCREW, RETAINING STRIP TO C	2		
19		38052	STRIP, RETAINING - TRIM COVEI	1		
20	10	48408	SCREW, RETAINING STRIP TO C	6		