



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1630	7360A29	GEAR HOUSING ASSEMBLY, COI	1		
-	1630	7360A30	GEAR HOUSING ASSEMBLY, COI	1		
1	1630	7360A11	GEAR HOUSING ASSEMBLY	1		
2	16	58138	STUD, GEAR HOUSING (3-1/2	1		
3	16	58136	STUD, WATER PUMP HOUSII	2		
4	31	22756	ROLLER BEARING - DRIVE SI	1		
5	17	20032	DOWEL PIN - LOCATING	1		
6	26	33613	SEAL, RUBBER - WATER INT.	1		3
7	23	86215	BEARING, NYLON - INTAKE T	1		
8	35	33425	SCREEN, WATER INTAKE	1		
9	10	25612	SCREW, WATER INTAKE SCF	1		
10	43	98696	PINION GEAR	1		
11	14	30377	TAB WASHER, PINION GEAR S	1		
12	10	30376	SCREW, PINION GEAR TO DRIP	1		
13	45	95873A 1	DRIVE SHAFT (SHORT SHAFT)	1	USE WITH ?47-89980! IMPELLER	
13	45	95874A 1	DRIVE SHAFT (LONG SHAFT)	1	USE WITH ?47-89980! IMPELLER	
14	15	30527A 1	SHIM ASSEMBLY, BALL BEARIN	AR		5
15	30	70944	BALL BEARING - DRIVE SHAFT	1		
16	53	30523	RETAINING RING - BALL BEARIN	1		
17	15	30527A 1	SHIM ASSEMBLY, BALL BEARIN	AR		5
18	46	70941A 1	WATER PUMP HSG.	1	USE WITH ?47-89981! IMPELLER	
18	46	92970A 1	WATER PUMP HSG.	1	USE WITH ?47-89980! IMPELLER	
19	25	29439	"O" RING	1		3
20	26	30900	OIL SEAL (USE WITH 47-8998	1		
20	26	96063	OIL SEAL (USE WITH 47-8998	1		
21		70977	INSERT	1		
22	26	33613	SEAL, WATER INTAKE TUBE	1		3
23	32	34293	TUBE, WATER INTAKE	1		
24	28	56655	KEY, IMPELLER DRIVE	1		
25	47	89981	IMPELLER (MOLDED 47-89981	1		
25	47	89980	IMPELLER (MOLDED 47-89980	1		
26		46895	PLATE, FACE - WATER PUMP	1		
27		93224A 1	WATER PUMP COVER ASSEMBL	1		
28	26	36558	SEAL, WATER PUMP COVER	1		3
30	26	30913	OIL SEAL, WATER PUMP COVE	1		
31	12	20533	WASHER	2	WATER PUMP HOUSING AND C	
32	11	13438	NUT, WATER PUMP HOUSING	2		
33	25	30526	RING, RUBBER - CENTRIFUGAI	1		3
34	23	31792	SLEEVE, GUIDE - INLET TUBE	1		
-	27	78139A80	GASKET SET			
-	46	70941A2	WATER PUMP KIT		USE WITH ?47-89981! IMPELLER	