

				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1529	1564A 2	DRIVE SHAFT HOUSING ASSEMBLY	1		
1	1533	1565A 1	DRIVE SHAFT HOUSING ASSEMBLY	.1		
2	16	29080	STUD, DRIVE SHAFT HOUSING	2,2		
3	32	26490	TUBE, WATER INLET	1,		
3	32	27867	TUBE, WATER INLET	.1		
4	26	26207	SEAL, RUBBER - WATER INLET	1,1		
5	27	26198	GASKET, DRIVE SHAFT HOUSING	1,1		
6	12	20086	WASHER, POWERHEAD STUDS	2,2		
7	11	20509	NUT, POWERHEAD STUDS	2,2		
8	11	23161	NUT, POWERHEADS STUDS	6,6		
9	10	29081	SCREW, GEAR HOUSING TO DR	1,1		
10	11	22178	NUT, GEAR HOUSING AND DR	5,5		
11		25305	CAP, RUBBER - UPPER MOUNT	2,2		
12	11	22178	NUT, UPPER MOUNT BOLT	2,2		
13	23	27725	SPACER, UPPER MOUNT BOLT	2,2		
14	12	27728	WASHER, UPPER MOUNT BOLT	2,2		
15	12	27726	WASHER, RUBBER - UPPER MO	2,2		
16	12	27727	WASHER, UPPER MOUNT BOLT	2,2		
17		26218	COVER, UPPER MOUNT - OUT	2,2		
18		26217	COVER, UPPER MOUNT - INSIDE	2,2		
19		27729	MOUNT, RUBBER - UPPER	2,2		
20		24929	PACKING, "U" CUP	2,2		
21	10	28773	SCREW, UPPER MOUNT COVER	4,4		
22	10	28775	SCREW, UPPER MOUNT COVER	2,2		
22	10	29389	SCREW, UPPER MOUNT COVER	2,2		
23	12	29245	WASHER, UPPER MOUNT COVE	8,8		
24	11	29322	NUT, UPPER MOUNT COVER SC	8,8		
25		25067	BUMPER, RUBBER - MOUNTING	2,2		
26	10	24874	SCREW, UPPER MOUNT (5 1/2")	2,2		
27		26211	MOUNT, RUBBER - LOWER	2,2		
28	12	24872	WASHER, MOUNTING SCREW	4,4		
29	11	25096	NUT, MOUNTING SCREW	2,2		
30		26336	COVER, LOWER MOUNT (PORT)	1,1		
30		26337	COVER, LOWER MOUNT (STARB	1,1		
31	10	29256	SCREW, LOWER MOUNT COVE	6,6		

