



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14817A 2	FUEL MANAGEMENT ASSEMBLY	1		
2		67748	ROLLER, CAM	1		
3		18715	FUEL INJECTOR	6		
4	35	17422	FILTER, INJECTOR	1		
5	84	15443	HARNES KIT	1		
6	35	15442	FUEL FILTER KIT	1		
7	35	15028	FUEL FILTER	1		
8	10	40003 4	SCREW, FILTER COVER	1		
9	13	40025 5	LOCKWASHER, COVER SCRE	1		
10	32	13503 77	HOSE (1/2" O.D.)	1		
11	32	99126 88	HOSE (1/8" I.D.)	1		
12	32	99130122	HOSE (3/32" I.D.)	1		
13		15027	REGULATOR, PRESSURE	1		
14		814233	ELBOW KIT	1		
15	27	18791	GASKET, PRESSURE REGULA	1		
16		814012	PLATE, PRESSURE REGULATI	1		
17	10	814076	SCREW	1	AS REQUIRED	
18		814010	COVER KIT	1		
19	10	40019 87	SCREW, COVER TO SEPARATC	6		
20	13	26995	LOCKWASHER, COVER SCREW	6		
21	26	18790	SEAL, VAPOR SEPARATOR	1		
22		15029	O-RING AND SEAL KIT	1		
23		15446	FLOAT VALVE KIT	1		
24		15445	FLOAT KIT	1		
25		814011	BODY KIT	1		
26	21	42481	CHECK VALVE	1		
27	10	40003 32	SCREW, SEPARATOR TO FUEL	3		
28		15444	LINK	1		
29	21	18241	CHECK VALVE	1		
30	20	18348	SHUT-OFF VALVE	1		
31	26	18792	SEAL, INJECTOR MANIFOLD	1		
32	23	19275	SPACER	1		
33	25	88033	GROMMET	3		
34	23	814913	SPACER	3		
35	12	57427	WASHER (LARGE)	3		
36	12	20346	WASHER (SMALL)	3		
37	54	13791	CLAMP, HOSE	1		
38	32	13503 77	TUBING (1-3/4 IN.)	1		
39	54	90077	STA-STRAP	1	AS REQUIRED	
40		14639	BLANKET, FUEL PUMP	1		
41		14640T	COVER, FUEL PUMP	1		