



10 669

2001B

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---|----------|---|
| 1 | 872241 | 1 | Starter motor | | ALSO AVAILABLE AS AN EXCHANGE PART. SN-2300059791 |
| | | | | 030-1128 | |
| | 872888 | 1 | Starter motor | | 1-POLE. AS A SPARE PART FOR 2001, 2001B, 2001AG, 2001BG USE STARTER MOTOR 872887.. ALSO AVAILABLE AS AN EXCHANGE PART. SN2300059792- |
| | | | | 030-1128 | |
| | 872887 | 1 | Starter motor | | 1-POLE. STARTER MOTOR 872887 IS ONLY TO BE USED AS A SPARE PART FOR 2001, 2001B, 2001AG, 2001BG. |
| | 3803217 | 1 | Starter motor, exch | | Exchange unit |
| | | | | 030-1100 | |
| 2 | 959257 | 2 | Screw | | |
| 3 | 940280 | 2 | Spring washer | | |
| 4 | 943194 | 2 | Washer | | |
| 5 | 955782 | 1 | Nut | | M8 |
| 6 | 872242 | 1 | Relay | | |
| 7 | 861317 | 1 | Bracket | | (860884) |
| 8 | 965198 | 2 | Screw | | |
| 9 | 946441 | 2 | Screw | | |
| 10 | 945987 | 1 | Lock washer | | |
| 11 | 855314 | 1 | Nut | | |
| 12 | 946440 | 1 | Flange screw | | |
| 13 | 860878 | 1 | Current bar | | |
| 14 | | 1 | ALTERNATOR AND INSTALLATION COMPONENTS | 030-0820 | |
| 15 | 840672 | 1 | Attaching plate | | |
| 16 | 941793 | 2 | Screw | | |
| 17 | 824823 | 1 | Fuse box | | |
| 18 | 955247 | 1 | Screw | | |
| 19 | 955780 | 1 | Nut | | |
| 20 | 876037 | 1 | Relay kit | | 12V/30A |
| 21 | 860143 | 1 | Wiring harness | | |
| | | X | · CABLES AND CABLE TERMINALS | 030-1351 | |
| 22 | 955119 | 4 | Screw | | |
| 23 | 846648 | X | Extension cable | | L = 3000 MM |
| | 846649 | X | Extension cable | | L = 5000 MM |
| | 846650 | X | Extension cable | | L = 7000 MM |
| 24 | 859057 | 1 | Instrument panel | | |
| | | | | 030-1336 | |
| 25 | 863169 | 1 | Pressure monitor | | |
| 26 | 858229 | 1 | Thermo monitor | | |
| 27 | 947624 | 1 | Gasket | | |
| 28 | 846615 | X | Sealing ring | | |
| 29 | 948210 | X | Strip clamp | | |