



10716

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	859553	1	Starter motor		2-POLE. REPLACED BY 1-POLE STARTER MOTOR 872241 AND INSTALLATION KIT 872381. ALSO AVAILABLE AS AN EXCHANGE PART.
				030-1127	
	872241	1	Starter motor, STARTER MOTOR		1-POLE. ALSO AVAILABLE AS AN EXCHANGE PART.
					SN2300052118-
				030-1128	
2	959257	2	Screw		
3	940280	2	Spring washer		
4	943194	2	Washer		
5	955782	1	Nut		
6	872242	1	Relay		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
7	860884	1	Bracket		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
8	965198	2	Screw		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
9	946441	2	Screw		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
10	945987	1	Lock washer		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
11	855314	1	Nut		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
12	946440	1	Flange screw		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
13	860878	1	Current bar		SN2300052118-. INCLUDED IN INSTALLATION KIT 872381 FOR CHANGING FROM 2-POLE TO 1-POLE STARTER MOTOR.
14	858838	1	Alternator, ALTERNATOR AND INSTALLATION COMPONENTS	030-0775	
15	840672	1	Attaching plate		
16	941793	2	Screw		
17	824823	1	Fuse box		
18	955247	1	Screw		
19	955780	1	Nut		
20	876037	1	Relay kit		12V/30A
21	860143	1	Wiring harness		
22	955119	4	Screw		
23	846648	X	Extension cable		L = 3000 MM
	846649	X	Extension cable		L = 5000 MM
	846650	X	Extension cable		L = 7000 MM
24	859058	1	Instrument panel		
				030-1337	
25	863169	1	Pressure monitor		
26	858229	1	Thermo monitor		
27	947624	1	Gasket		
28	846615	X	Sealing ring		
29	948210	X	Strip clamp, STRIP CLAMP		
	872381	1	· Mounting kit, STARTER MOTOR		