
2001,2001AG,2001B,2001BG





Upd: 22 NOV 2005

2001,2001AG,2001B,2001BG

PART NO.	QTY	DESCRIPTION		NOTES
860076	1	Cylinder head		ALSO AVAILABLE AS AN EXCHANGE PART CONSISTING OF CYLINDER HEAD, INTAKE AND EXHAUST VALVES, VALVE SPRINGS, WASHERS AND
				LOCKS.
				Exchange unit
			IK	((00011)
				(192211)
			ш	
			IN	
			II/	
			II	L = 100 MM
				L = 100 IVIIVI
				REPL BY 861061
861061				VALVE COVER KIT 861061 CONSISTS OF 1EA VALVE COVER 840681,1EA LEVER 840590,1EA SCREW 940102,1EA O-RING 955976 AND 1EA WASHER 960138.THE KIT IS ALSO INTENDED FOR LATER VERSION WHERE HOLE FOR DECOMPRESSION SHAFT IS MISSING
859042	1	Gasket	IK	
940142	1	Screw		
840441	1	Spacer sleeve		
840442	1	Rubber seal		
840900	1			
	1			
				SEE GROUP 2C
	-			INCLUDED IN VALVE COVER KIT 861061 BUT HAS BEEN REMOVED AS STANDARD FROM SN2300059085-
				INCLUDED IN VALVE COVER KIT 861061 BUT HAS BEEN REMOVED AS STANDARD FROM SN2300059085- INCLUDED IN VALVE COVER KIT 861061 BUT HAS BEEN REMOVED AS
				STANDARD FROM SN2300059085-
				SEE GROUP 2B
				OLL GROOT ZD
	860076 3803160 840281 860267 945221 477024 840842 418445 858461 840569 970888 840210 840681 861061 859042 940142 840441 840442	860076 1 3803160 1 840281 2 860267 1 945221 1 477024 4 840842 1 418445 1 858461 1 970888 6 840210 6 840681 1 861061 1 840441 1 840441 1 840441 1 840900 1 838928 1 840590 1 940102 1 960138 1 840831 1 840732 1 418445 1 840740 1	860076 1 Cylinder head 3803160 1 Cylinder head, exch 840281 2 · Valve guide 860267 1 · Spray sleeve 945221 1 · O-ring 477024 4 · Expansion plug 840842 1 · Distribution pipe 418445 1 · Sealing ring 858461 1 · Valve seat 840569 1 Gasket 970888 6 Screw 840210 6 Washer 840681 1 Valve cover 840681 1 Valve cover 840442 1 Screw 840442 1 Rubber seal 840900 1 Washer 838928 1 Plug 838929 1 Zinc anod 924066 1 Stud 840590 1 Lever 940102 1 Screw 960138 1 Was	Second 1 Cylinder head Second Second

7726000 - 02A - 02A-4020 10207 Upd: 22 NOV 2005