



3813

REF	PART NO.	QTY	DESCRIPTION
1		1	
2		1	• pump housing
3	826239	1	• Locking pin
4		1	• cover
5	808275	1	• Gasket
6	804776	6	• Screw
7	827019	2	• Washer
8		1	• impeller
9		1	• wear plate
10		1	• cam
11	808285	1	• Screw
12	809444	1	• Lock ring
13	822708	1	• Sealing
14		1	• bearing housing
15		1	• shaft
16		1	• slinger
17	825737	1	• Sealing
18	11013	2	• Ball bearing
19	914533	1	• Snap ring
20	940180	1	• Hexagon screw
21	955825	1	• Hexagon nut
22	941906	1	• Spring washer
	875594	1	Repair kit
	875593	1	Impeller kit