



6380

TD100ARC

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	467517	1	Oil pump		
				02A-1250	
2	190529	2	Lock washer		
3	955538	4	Screw		
4	422051	1	Tube		
5	896682	1	Bracket		
6	414621	1	Strainer		
7	118125	1	Lock ring		
8	925060	2	O-ring	IK	
9	955530	2	Screw		
10	941907	2	Spring washer		
11	896684	1	Tube		
12	940135	2	Screw		
13	941907	2	Spring washer		
14	422178	1	Oil pipe		EARLY TYPE
15	949656	1	O-ring	IK	EARLY TYPE (191058)
16	955530	2	Screw		EARLY TYPE
17	941907	2	Spring washer		
18	466907	1	Fitting		
19	953235	2	Stud		EARLY TYPE
20	955826	2	Nut		EARLY TYPE
21	955894	4	Washer		EARLY TYPE
22	940113	2	Screw		EARLY TYPE
23	941907	2	Spring washer		EARLY TYPE
24	941907	2	Spring washer		(955921) EARLY TYPE
24A	942402	4	Flange screw		LATE TYPE
25	896680	1	Sump		
26	947807	1	Nipple		
27	422025	1	Gasket	IK	
28	956570	41	Screw		
29	941907	41	Spring washer		
30	821101	1	Oil dipstick		
31	801480	1	Sleeve		
32	802057	1	Inspection lid		
33	800877	2	Inspection lid		
	800877	1	Inspection lid		AQ140A MO-7019/XXXX. AQ120B MO-602/XXXX.
34	823185	3	Gasket	IK	
35			OIL AND FUEL SUPERVISION WITH INSTALLATION COMPONENTS		SEE GROUP 3
36	956569	36	Screw		
37	11992	36	Gasket	IK	
38	421123	1	Reducing valve		
39	925062	1	O-ring	IK	
40	940100	2	Screw		
41	941906	2	Spring washer		
42	896775	1	Tube		
43	802287	1	Gasket	IK	
44	955525	2	Screw		
45	941907	2	Spring washer		
46	1545270	1	Oil feed pipe		LATE TYPE
47	1545272	1	Flange		LATE TYPE
48	1545271	1	Sealing ring		LATE TYPE
49	955531	2	Screw		LATE TYPE
50	941907	2	Spring washer		LATE TYPE
51	1545011	1	Bracket		LATE TYPE
52	955523	2	Screw		LATE TYPE
53	941907	2	Spring washer		LATE TYPE
54	1545203	1	Bracket		LATE TYPE
55	943121	1	Clamp		LATE TYPE
56	940117	3	Screw		LATE TYPE
57	1545269	3	Sleeve		LATE TYPE

TD100ARC

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
58	960140	3	Washer		LATE TYPE
59	955825	3	Nut		LATE TYPE
60		1	OIL FILTER WITH INSTALLATION COMPONENTS	02A-1300	
61		1	OIL BILGE PUMP WITH INSTALLATION COMPONENTS	02A-1350 02A-1550	
				02A-1540	
				02A-1545	

