



THERMOSTAT HOUSING AND EXPANSION TANK WITH INSTALLATION COMPONENTS: TAMD31A

02B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	838703	1	Adapter		
2	1542187	1	Gasket		
3	955295	4	Screw		
4	838704	1	Thermostat housing		
5	838739	1	Tube		
6	968927	2	O-ring		
7	941907	2	Spring washer		
8	965183	2	Flange screw		
9	952077	2	Plug		
10	1542198	1	Sealing ring	02B-0955	
11	876128	1	Thermostat kit		(273952) 81%Z9
11A	416033	1	· Sealing ring		
12	875849	1	Thermostat kit		81%Z9. WITH AIR VENTING VALVE
13	416033	1	· Sealing ring		
14	876145	1	Retainer kit		
14A	859229	2	· Retainer		
15	838807	1	· Sealing ring		
16	963554	2	· Screw		
17	966170	2	· Nut		
18	965217	4	Flange screw		
19	858897	1	Air vent pipe		REPL BY 860214. TURBO-THERMOSTAT HOUSING
	860214	1	Air vent hose		TURBO-HEAT EXCHANGER-THERMOSTAT HOUSING
20	11994	3	Gasket		
21	858750	1	Banjo nipple		
22	947975	1	Hollow screw		
23	943366	X	Hose		
24	943470	2	Hose clamp		
25	968927	1	O-ring		
26	827151	1	Temperature sensor		12V
27	833927	1	Thermo monitor		12V
28	957181	2	Gasket		
29	858519	1	Tube		
30	953001	2	Stud	02B-2275	
31	941907	2	Spring washer		
32	971095	2	Nut		(945409)
33	820917	2	Spacer sleeve		
34	943475	2	Hose clamp		
35	944386	X	Hose		L = 90 MM
36	838779	1	Coolant pipe		AFTER COOLER-OUTLET
37	843759	1	Expansion tank		
38	844624	1	Pressure cap		
39	947660	2	Plug		(836268)
40	843260	1	Bracket		
41	843266	1	Clamp		
42	858889	1	Decal		REPLACED BY DECAL KIT 876234
	876234	1	Decal set		
43	952969	X	Rubber hose		EXPANSION TANK-INLET
44	943472	1	Hose clamp		
45	946544	1	Flange screw		
46	967645	1	Clamp		
47	955892	1	Washer		
48	838789	1	Housing		
49	941907	4	Spring washer		