



5795

--

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER AND THERMOSTAT WITH INSTALLATION COMPONENTS	02B-0200	
2		1	CIRCULATION PUMP AND DRIVE DEVICE WITH INSTALLATION COMPONENTS	02B-0300	
3		1	OIL COOLER WITH INSTALLATION COMPONENTS	02B-0350	
4		1	SEA WATER PUMP WITH INSTALLATION COMPONENTS	02B-0400	
6		1	TURBO AND AIR FILTER WITH INSTALLATION COMPONENTS	02B-0550	
7		1	INDUCTION AND EXHAUST MANIFOLD WITH INSTALLATION COMPONENTS	02B-0700	
8	192134	1	Plug		
9	843990	1	Coolant pipe		
10	836778	2	Gasket		
11	940135	4	Screw		
12	941907	4	Spring washer		
13	843942	1	Fitting		
14	862703	1	Gasket		(800389)
15	955296	2	Screw		
16	941907	2	Spring washer		
17	836754	1	Flange		
18	836778	1	Gasket		
19	940135	2	Screw		
20	941907	2	Spring washer		
21	943717	2	Clamp		
22	940100	2	Screw		
23	941906	2	Spring washer		
24	955825	2	Nut		