



6189

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---|----------|--|
| 1 | 466387 | 1 | Oil pump | | |
| | | | | 02A-0400 | |
| 2 | 421404 | 1 | Baffle | | |
| 3 | 955538 | 4 | Screw | | |
| 4 | 421051 | 1 | Oil pipe | | |
| 5 | 414621 | 1 | Strainer | | |
| 6 | 118125 | 1 | Lock ring | | |
| 7 | 896693 | 1 | Tube | | |
| 8 | 949657 | 2 | O-ring | IK | |
| 9 | 940135 | 2 | Screw | | |
| 10 | 941907 | 2 | Spring washer | | |
| 11 | 955530 | 2 | Screw | | |
| 12 | 941907 | 2 | Spring washer | | |
| 13 | 421049 | 1 | Oil pipe | | |
| 14 | 949656 | 1 | O-ring | IK | |
| 15 | 955530 | 2 | Screw | | |
| 16 | 941907 | 2 | Spring washer | | |
| 17 | 466906 | 1 | Fitting | | |
| 18 | 896773 | 1 | Bracket | | |
| 19 | 955523 | 2 | Screw | | EARLY TYPE |
| 19A | 942402 | 4 | Flange screw | | LATE TYPE |
| 20 | 941907 | 2 | Spring washer | | EARLY TYPE |
| 21 | 955894 | 2 | Washer | | EARLY TYPE |
| 22 | 953236 | 2 | Stud | | (953235) |
| 23 | 955826 | 2 | Nut | | EARLY TYPE |
| 24 | 941907 | 2 | Spring washer | | EARLY TYPE |
| 25 | 955894 | 2 | Washer | | EARLY TYPE |
| 26 | 843748 | 1 | Oil pan | | |
| 27 | 424919 | 1 | Gasket | IK | (421025) |
| 28 | 800877 | 1 | Inspection lid | | WHEN OIL SUPERVISION IS NOT INSTALLED. |
| 29 | 843838 | 1 | Hatch | | |
| 30 | 862597 | 2 | Gasket | IK | (823185) |
| 31 | 956569 | 24 | Screw | | |
| 32 | 11992 | 24 | Gasket | IK | |
| 33 | 956570 | 36 | Screw | | |
| 34 | 941907 | 36 | Spring washer | | |
| 35 | 968216 | 1 | Plug | | (951906) |
| 36 | 844593 | 1 | Bracket | | |
| 37 | 862711 | 1 | Gasket | | (842928) |
| 38 | 940135 | 3 | Screw | | |
| 39 | 941907 | 3 | Spring washer | | |
| 40 | 823016 | 1 | Oil dipstick | | |
| 41 | 955982 | 1 | O-ring | | |
| 42 | 843844 | 1 | Tube | | |
| 43 | 957185 | 1 | Gasket | | |
| 44 | 421123 | 1 | Reducing valve | | |
| 45 | 949721 | 1 | O-ring | IK | |
| 46 | 940100 | 2 | Screw | | |
| 47 | 941906 | 2 | Spring washer | | |
| 48 | | 1 | OIL FILTER AND INSTALLATION COMPONENTS | 02A-0450 | |
| 49 | | 1 | OIL AND FUEL SUPERVISION WITH INSTALLATION COMPONENTS | | SEE GROUP 3 |

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---|----------|-------|
| 58 | | 1 | OIL BILGE PUMP WITH INSTALLATION COMPONENTS | 02A-0500 | |
| 59 | 947061 | 2 | Gasket | IK | |