



22425

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3581402	1	Bracket	
2	1348141	3	Absorber	
3	945407	6	Flange nut	
4	3581530	1	Bracket	
5	947760	1	Flange screw	L=40mm
	948217	1	Flange screw	L=45mm
6	873742	1	Wiring harness	
7	948211	X	Strip clamp	
8	955119	4	Screw	
9	966689	1	Fuse	
10	881797	1	Rotation speed relay, rpm	(872616)
11	968476	2	Flange screw	
12	860779	1	Cover	
13	846736	3	Lock screw	
14	941904	3	Spring washer	
15	960137	3	Washer	
16	873740	1	Relay	12V 40A
17	968476	1	Flange screw	
18	846648	X	Extension cable	L=3,0m
	846649	X	Extension cable	L=5,0m
	846650	X	Extension cable	L=7,0m
	873838	X	Extension cable	L=9,0m
	873839	X	Extension cable	L=11,0m
19	1140598	1	Y-koppling	For double steering positions.
20	948211	3	Strip clamp	
21	3819905	1	Fuse	(856355)
22		1	Cable kit	POWER TRIM
23		1	Cable kit	POWER TRIM
				SEE GROUP 44
24	955781	2	Nut	
25	1234326	1	Protective cap	
26	960140	1	Washer	
27	955893	2	Washer	
28	947542	1	Screw	
29	955893	3	Washer	
30	945407	1	Flange nut	
31	866835	1	Pressure sensor, oil-engine	0-10bar
	866836	1	Pressure sensor, oil-engine	ALT,0-10bar. For double steering positions.
32	863169	1	Pressure monitor, oil-pressure	0,7bar
33	873066	1	Thermo monitor, coolant water temp.	97°C
34	827151	1	Temperature sensor, coolant water temp.	40-120°C
	840074	1	Temperature sensor, coolant water temp.	ALT, 120°C. For double steering positions.
35	957181	2	Gasket	
36	862251	1	Tachometer sensor	For revolution relay.
37	957181	1	Gasket	
38	860970	1	Bracket	
39	946544	2	Flange screw	
40	874498	1	Position sensor, rpm	(872597)
41	956050	2	Screw	
42	955890	4	Washer	
43	966650	2	Lock nut	
44	948211	X	Strip clamp	
45	873717	1	Resistor	LATE TYPE
46	952627	1	Clamp	
47	3581444	1	Bracket	