



22426

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3581402	1	Bracket	
2	1348141	3	Absorber	
3	3581530	1	Bracket	
4	947760	1	Flange screw	L=40mm
	948217	1	Flange screw	L=45mm
5	3581444	1	Bracket	
6	860779	1	Cover	
7	846736	3	Lock screw	
8	941904	3	Spring washer	
9	960137	3	Washer	
10	873749	1	Wiring harness	
11	873740	1	Relay	
12	968476	5	Flange screw	
13	1324492	3	Relay	
14	966689	2	Fuse	8A
15	955119	4	Screw	
16	846648	X	Extension cable	L=3,0m
	846649	X	Extension cable	L=5,0m
	846650	X	Extension cable	L=7,0m
	873838	X	Extension cable	L=9,0m
	873839	X	Extension cable	L=11,0m
17	945407	6	Flange nut	
18	948211	X	Strip clamp	
19	3515093	1	Sender, rpm	
20	963684	1	Screw	
21	1140598	1	Y-koppling	For double steering positions.
22	948211	3	Strip clamp	
23	866835	1	Pressure sensor, oil-engine	0-10bar
	866836	1	Pressure sensor, oil-engine	ALT,0-10bar. For double steering positions.
24	863169	1	Pressure monitor, oil-pressure	0,7bar
25	8141474	1	Temperature sensor, air inlet	
26	947624	1	Gasket	
27	862154	1	Temperature sensor, coolant water	120°C
	862567	1	Temperature sensor, coolant water	ALT. For double steering positions.
28	11998	1	Gasket	
29	1624368	1	Temperature sensor, coolant water	EDC
30	11996	1	Gasket	
31	946671	1	Flange screw	
32	843075	1	Sleeve	
33	965558	2	Bracket	
34	946544	2	Flange screw	
35	952635	2	Clamp	
36	945407	2	Flange nut	
37	946671	2	Flange screw	
38	965558	2	Bracket	
39	843075	2	Sleeve	
40	965200	4	Flange screw	
41	6776926	2	Terminal block	
42	949874	4	Lock nut	
43	955893	5	Washer	
44	960140	1	Washer	POS
45	945407	2	Flange nut	
46	1234326	1	Protective cap	POS
47	949746	1	Clamp, alternator	(946834)
48	3819905	1	Fuse	(856355)
49		1	Cable kit	POWER TRIM
50		1	Cable kit	POWER TRIM
				SEE GROUP 44
51	955781	2	Nut	
52	1234326	1	Protective cap	
53	960140	1	Washer	
54	955893	2	Washer	
55	946934	1	Flange screw	
56	945407	1	Flange nut	

