



16790

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	860417	1	Bracket	REPL BY 3581402
	3581402	1	Bracket	
1A	1348141	3	Absorber	FOR 3581402
2	945407	6	Flange nut	
2A	968855	2	Flange screw	FOR 3580668
3	3580668	1	Bracket	REPL BY 3581530
	3581530	1	Bracket	
4	947760	1	Flange screw	L=40mm
	948217	1	Flange screw	L=45mm
5	873551	1	Wiring harness	SN-2204215630
	873742	1	Wiring harness	SN2204215631-
6	948211	X	Strip clamp	
7	955119	4	Screw	
8	966689	1	Fuse	
9	872616	1	Relay	
10	968476	2	Flange screw	
11	860779	1	Cover	
12	846736	3	Lock screw	
13	941904	3	Spring washer	
14	960137	3	Washer	
15	860339	1	Relay	12V 50A, SN-2204215630
	873740	1	Relay	12V 40A, SN2204215631-
16	968476	1	Flange screw	
17	846648	1	Extension cable	L=3,0m
	846649	1	Extension cable	L=5,0m
	846650	1	Extension cable	L=7,0m
18	1140598	1	Y-koppling	For double steering positions.
19	856355	1	Fuse	
20		1	Cable kit	POWER TRIM
21		1	Cable kit	POWER TRIM SEE GROUP 44
22	955781	2	Nut	
23	1234326	1	Protective cap	
24	960140	1	Washer	
25	955893	2	Washer	
26	947542	1	Screw	
27	955893	3	Washer	
28	945407	1	Flange nut	
29	866835	1	Pressure sensor, oil-engine	0-10bar
	866836	1	Pressure sensor, oil-engine	ALT,0-10bar. For double steering positions.
30	863169	1	Pressure monitor, oil-pressure	0,7bar
31	873066	1	Thermo monitor, coolant water temp.	97°C
32	827151	1	Temperature sensor, coolant water temp.	40-120°C
	840074	1	Temperature sensor, coolant water temp.	ALT, 120°C. For double instruments.
33	947624	2	Gasket	
34	862251	1	Tachometer sensor	For revolution relay.
35	947624	1	Gasket	
36	860970	1	Bracket	
37	946544	2	Flange screw	
38	872597	1	Sender	
39	956050	2	Screw	
40	955890	4	Washer	
41	966650	2	Lock nut	
42	948211	X	Strip clamp	
43	873717	1	Resistor	LATE TYPE
44	952627	1	Clamp	
45	3581444	1	Bracket	FOR 3581402