



2852

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	839211	1	Upper gear	OBSOLETE PART
2	832126	1	• Housing	OBSOLETE PART
3	961638	1	• • Grooved pin	OBSOLETE PART
4	832139	1	• Gear housing cover	OBSOLETE PART
5	804342	1	• • Screw	OBSOLETE PART
6	804344	1	• • Gasket	
7	813952	1	• • Shaft	OBSOLETE PART
8	832140	1	• • Washer	OBSOLETE PART
9	832143	1	• Gear housing cover	OBSOLETE PART
10	950512	1	• • Pin	OBSOLETE PART
11	839220	1	• Cable attachment	OBSOLETE PART
12	21471054	1	• Bracket	
13	819068	1	• Washer	
14	950022	2	• Cross recessed screw	OBSOLETE PART
15	940092	2	• Hexagon nut	
16	941906	4	• Spring washer	
17	940094	4	• Hexagon screw	
18	839212	1	• Gear set	OBSOLETE PART
19	181287	2	• Ball bearing	
20	181290	2	• Ball bearing	OBSOLETE PART
21	832920	1	• Bearing box	OBSOLETE PART
22	832921	1	• Bearing cover	OBSOLETE PART
23	956571	6	• Hex. socket screw	
24	941907	6	• Spring washer	
25	832952	1	• Gasket	
26	925094	1	• O-ring	
27	955995	1	• O-ring	
28	832128	X	• Intermediate ring	TH = 11,850 MM, OBSOLETE PART
	832129	X	• Intermediate ring	TH = 11,875 MM, OBSOLETE PART
	832130	X	• Intermediate ring	TH = 11,900 MM, OBSOLETE PART
	832131	X	• Intermediate ring	TH = 11,925 MM, OBSOLETE PART
	832132	X	• Intermediate ring	TH = 11,950 MM, OBSOLETE PART
	832133	X	• Intermediate ring	TH = 11,975 MM, OBSOLETE PART
	832134	X	• Intermediate ring	TH = 11,000 MM, OBSOLETE PART
29	832923	1	• Lock nut	OBSOLETE PART
30	907025	1	• Lock washer	
31	804205	1	• Cover	OBSOLETE PART
32	958856	1	• Sealing ring	
33	940135	6	• Hexagon screw	
34	941907	6	• Spring washer	
35	813949	1	• Bearing sleeve	OBSOLETE PART
36	951953	1	• Spring pin	
37	925257	2	• O-ring	
38	804301	X	• Adjusting washer	TH = 0,05 MM
	804221	X	• Adjusting washer	TH = 0.1mm, OBSOLETE PART
	804394	X	• Adjusting washer	TH = 0.2mm, OBSOLETE PART
39	84219	X	• Shim	TH = 0,1 MM, EARLY TYPE
40	804299	X	• Adjusting washer	TH = 0,05 MM, OBSOLETE PART
	804220	X	• Adjusting washer	TH = 0.1mm, OBSOLETE PART
	804393	X	• Adjusting washer	TH = 0.2mm, OBSOLETE PART
41	804298	X	• Adjusting washer	TH = 0.5mm, OBSOLETE PART
	804219	X	• Adjusting washer	TH = 0.1mm, OBSOLETE PART
	804392	X	• Adjusting washer	TH = 0.2mm, OBSOLETE PART
42	875169	1	• Sliding sleeve	OBSOLETE PART
43		1	• • sliding sleeve	
44	955076	1	• • Plug	OBSOLETE PART
45	181268	4	• Needle roller assemb	
46	941280	1	• Lock ring	OBSOLETE PART
47	813970	1	• Spring	
48	813939	2	• Spacer ring	
49	850761	2	• Pin	
50	814030	2	• Lock ring	
51	813943	1	• Eccentric piston	OBSOLETE PART

REF	PART NO.	QTY	DESCRIPTION	NOTES
52	813945	1	• Spring	
53	813999	1	• Needle bearing	OBSOLETE PART
54	205	1	• Ball	OBSOLETE PART
55	813942	1	• Eccentric shaft	OBSOLETE PART
56	958807	1	• Sealing ring	(940398)
57	839240	1	• Lever	OBSOLETE PART
58	959616	1	• Hexagon screw	OBSOLETE PART
59	813934	1	• Dog	
60	925093	1	• O-ring	
61	839288	1	• Tensioning din	OBSOLETE PART
62	832137	1	• Oil dipstick	OBSOLETE PART
63	804261	1	• Gasket	
64	940172	4	• Hexagon screw	
65	813941	X	• Spacer ring	TH=5.0mm
	813971	X	• Spacer ring	TH = 5,1 MM, OBSOLETE PART
	813972	X	• Spacer ring	TH = 5,2 MM, OBSOLETE PART
	813973	X	• Spacer ring	TH = 5,3 MM, OBSOLETE PART
	813974	X	• Spacer ring	TH = 5,4 MM, OBSOLETE PART
66	813674	1	• Cube	OBSOLETE PART
67	940191	1	• Washer	
68	907834	1	• Split pin	(17276)
69	804425	1	• Sign	OBSOLETE PART
70	804269	4	• Drive screw	
71	875512	4	• Rubber bellows	
72	961677	2	• Hose clamp	