



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	ALTERNATOR AND INSTALLATION COMPONENTS	030-0750	
2	833669	1	Starter motor		MO 1763-
	3803073	1	Starter motor, exch		Exchange unit
				030-1100	
3	833037	1	Bracket		
4	955319	3	Screw		
5	941908	3	Spring washer		
6	955344	2	Screw		
7	940280	2	Spring washer		
8	955784	2	Nut		
9	941907	1	Spring washer		
10	955782	1	Nut		
11	829587	1	Switch		SEE GROUP 2A
12	955945	1	Washer		
13	190663	1	Screw		
14	840074	1	Temperature sensor		
14	827151	1	Temperature sensor		MD17C/HD-HE SPEC 867600, MD17D/HD-HE SPEC 867684.
15	957181	1	Gasket	IK	
16	1502028	1	Tachometer sensor		
17	957181	1	Gasket	IK	
18	833908	1	Instrument panel		MO 5276-18402. REPLACED BY 840529.
				030-1250	
19	833607	1	Cable trunk		
20	833618	X	Extension cable\verl		L = 2000 MM
	833619	X	Extension cable\verl		L = 5000 MM
21		X	CABLES AND TERMINALS	030-1350	
22	824823	1	Fuse box		MO 1036-
23	950024	1	Screw		MO 1036-
25	952628	1	Clamp		
26	948210	X	Strip clamp		(827353)
27	840013	1	Instrument panel EXTRA		
28	839128	1	· Plug		
29	944540	4	· Screw		
30	834397	1	Voltmeter		
31	834374	1	· Voltmeter		
32	19923	1	· Bulb		
33	808175	1	· Bulb socket		
34	827940	1	Alarm kit		SEE GROUP 9
35	834400	1	Tank gauge DRINKING WATER		SEE GROUP 9
36	870980	1	Switch		
37	243700	1	· Handle		
38	955783	2	· Nut		
39	821042	1	Sign		
40	833216	1	Protecting casing		SEE GROUP 2A