



7147

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	ALTERNATOR AND INSTALLATION COMPONENTS	030-0750	
2	833669	1	Starter motor		MO 1763-
	3803073	1	Starter motor, exch		Exchange unit
				030-1100	
3	833037	1	Bracket		
4	955319	3	Screw		
5	941908	3	Spring washer		
6	955344	2	Screw		
	955345	2	Screw		L = 55 MM. MD17C SPEC 867600. MD17D SPEC 867684.
7	940280	2	Spring washer		
8	955784	2	Nut		
9	941907	1	Spring washer		
10	955782	1	Nut		
11	829587	1	Switch		SEE GROUP 2A
12	955945	1	Washer		
13	190663	1	Screw		
14	840074	1	Temperature sensor		MO-18902, SPEC 867681, -682, -683.
	827151	1	Temperature sensor		MO 18903-, SPEC 867681, -682, -683.
	827151	1	Temperature sensor		MD17C/HD-HE SPEC 867600, MD17D/HD-HE SPEC 867684.
15	18840	1	Gasket		
16	1502028	1	Tachometer sensor		
17	957181	1	Gasket	IK	
18	840529	1	Instrument panel		MO 18403-
				030-1260	
19	833607	1	Cable trunk		
20	833618	X	Extension cable\verl		L = 2000 MM
	833619	X	Extension cable\verl		L = 5000 MM
21		X	CABLES AND TERMINALS	030-1350	
22	824823	1	Fuse box		MO 1036-
23	950024	1	Screw		MO 1036-
24	829739	1	Bracket		SPEC 867422,-423,-426,-427,-428.
25	952628	1	Clamp		
26	948210	X	Strip clamp		(827353)
27	840013	1	Instrument panel EXTRA		
28	839128	1	· Plug		
29	944540	4	· Screw		
34	827940	1	Alarm kit		SEE GROUP 9
35	834400	1	Tank gauge DRINKING WATER		SEE GROUP 9
36	870980	1	Switch		
37	243700	1	· Handle		
38	955783	2	· Nut		
39	821042	1	Sign		