



6412

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	423259	6	Cylinder head	
	3803040	6	Cylinder head, exch	Exchange unit
2	423011	6	· Valve seat, INTAKE	STD D
	423208	6	· Valve seat, INTAKE	0,20MM O.S
3	468448	6	· Valve seat, EXHAUST	STD D
	468449	6	· Valve seat, EXHAUST	0,20MM O.S (423205)
4	422320	6	· Valve guide, INTAKE	
5	1545135	6	· Valve guide, EXHAUST	(421297)
6	468263	6	· Spray sleeve	
7	469205	6	· O-ring	IK
8	467365	12	· Plug	
9	469327	12	· Gasket	IK (422182)
10	950543	12	· Pin	
11	468210	6	· Sealing ring	
12	423016	6		BB115B, AQ130C MO-15301/XXXX. BB115A MO-1400/XXXX.
13	423017	6	Valve	BB115B, AQ130C MO-16931/XXXX. BB115A MO-1470/XXXX.
14	468066	12	Valve spring	MO4461/XXXX-. BB115B MO-XXXX/86908.
15	468067	12	Valve spring	MO4461/XXXX-. BB115B MO-XXXX/86908.
16	468064	12	Washer, UPPER	MO4461/XXXX-. BB115B MO-XXXX/86908.
17	468065	12	Washer, LOWER	MO4461/XXXX-. BB115B MO-XXXX/86908.
18	402418	24	Valve collet	
19	469456	12	Protecting ring	(407224)
20	469365	12	Valve cap	(417133)
21	423266	6	Bearing bracket	
22	423331	18	Screw	
23	423267	6	Shaft	
24	946778	12	· Cap plug	
25	950499	6	· Pin	
26	423263	12	Rocker arm	
27	422066	12	· Bushing	
28	423058	12	· Ball stud	
29	940175	12	· Nut	
30	423269	12	Washer	
31	914459	12	Lock ring	
32	423404	1	Cover	BB115B MOXXXX/86909-.
33	423403	5	Cover	
34	468963	6	Gasket	IK (468352)
35	955527	12	Screw	
36	942580	12	Gasket	IK
37	420292	1	Oil filler cap	
38	940096	1	Gasket	IK
39	275548	6	Gasket kit	
40	422413	6	· Sealing ring, OIL	IK
	422415	12	· Sealing ring, WATER	IK
	423326	12	· · Sealing ring, PUSH ROD	IK
41	423485	48	Screw	EARLY TYPE
42	423486	48	Washer	EARLY TYPE
42A	470261	48	Flange screw	LATE TYPE
43	949020	12	Pin	