



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	814056	1	Hydraulic lift	
2	809920	1	· Tube	
3	809921	1	· · Tube	
4	809956	1	· · Tube	
5	925063	1	· · O-ring	
6	955977	1	· · Rubber ring	
7	956554	4	· · Screw	
8	809902	1	· · Ball socket	
9	940170	4	· · Screw	
10	809923	1	· · Hydraulic cylinder	
11	809929	1	· · Bushing	
12	809930	1	· · Rubber collar	
13	809924	1	· · Guide rod	
14	813978	1	· · Ball socket	
15	813977	1	· · Protecting plate	
16	914450	2	· · Snap ring	
17	940155	4	· · Lock washer	
18	809993	1	· · Sealing ring	
19	230107	1	· Rubber hose	
20	18666	1	· Gasket	
21	954343	1	· Elbow nipple	
22		1	· CONNECTOR	EARLY TYPE. REPLACED BY 954315 + 954322.
	954315	X	· Tube	LATE TYPE L = 157 MM
22A	954322	2	· Cap nut	LATE TYPE
23	814322	1	· Switch	
24	813958	1	· Rubber cushion	
25	940171	4	· Screw	
26	940278	4	· Screw	
27	940178	2	· Screw	
28	809915	1	· Hydraulic pump	
29		1	· · HOUSING	
30	809919	1	· · Cover	
31	809938	1	· · · Bushing	
32		1	· · PLUNGER	
33	25930	2	· · Adjusting washer	
	120155	2	· · Spacer	
34	809951	1	· · Companion flange	
35	26694	1	· · Ball	
36	809952	1	· · Piston	
37	809946	1	· · Spring	
38	809947	1	· · Plug	
39	925257	1	· · O-ring	
40	950021	4	· · Screw	
41	941905	4	· · Spring washer	
42	662463	1	· · Cover	
43	897720	1	· Electric motor	
44	814456	4	· Nut	
45	944596	1	· Pin	
46	839275	1	· Carbon brush set	
	875356	1	Repair kit	
47	870670	2	· Relay	
48	813901	1	· Bracket	
49	955524	2	· Screw	
50	941907	2	· Spring washer	
51	950002	2	· Screw	
52	950045	1	· Screw	
53	61954	1	· Gasket	
54		X	· CABLES AND CABLE TERMINALS	SEE GROUP 3
55	875257	1	Mounting kit, MOUNTING KIT STEERING TUBE	
56		2	· SPACER WASHER	
57		1	· SHAFT	