



15898

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	861390	1	Electrical distribut		
2	3580949	1	Stay		
3		1	Screw		
4		2	Washer		
5		2	Nut		
6	873566	1	Fuse box		
7	955142	1	Screw		
8	873215	1	Wiring harness		
8A		X	Cables and terminals	124	
9	955119	4	Screw		
10	952630	1	Clamp		
11	876039	2	Relay kit		12V 20-30A (1504952)
11A	948663	2	Screw		
11B	955780	2	Nut		
12	1624394	1	Diode		
13	873397	1	Diode retainer		
14	846648	1	Extension cable		L=3,0m
	846649	1	Extension cable		L=5,0m
	846650	1	Extension cable		L=7,0m
14A	1140598	X	Y-koppling		For double steering positions.
15	873153	1	Pressure monitor, oil-pressure		
16	861873	1	Nipple		
17	858229	1	Thermo monitor		
18	947624	1	Gasket		
19	3580007	1	Connector		
20	873155	1	Sensor kit		
21	866835	1	• Pressure sensor, oil-pressure		0-10bar
22	861388	1	• Adapter		
23	947620	3	• Gasket		
24	861389	1	• Hollow screw		
25	843325	1	• Temperature sensor		120°C
26	947624	1	• Gasket		
27	3580084	3	Glow plug		
28		3	• Nut		
29		3	• Washer		
31	3580597	1	Current bar		
32		1	Nut		