




16596

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3580815	1	Heat exchanger	
2			Housing	
3	3580817	1	• Insert	
4	3580818	4	• O-ring	
5	3580968	1	• Plate	
6	3580820	1	• Cover	
7	959224	4	• Screw	
8			• Rim	
9	866761	1	• Pressure cap	
10	980093	2	Stud	
11	945408	2	Flange nut	
12	968006	8	Screw	
12A	941907	8	Spring washer	
13	3580853	1	Stay	
14	946173	2	Flange screw	
15	961670	1	Hose clamp	
16	859800	1	Hose	Thermostat housing-heat exchanger.
17	961670	1	Hose clamp	
18	3580930	1	Hose	Heat exchanger-water pump.
19	859785	1	Gasket	
20	966871	1	Tap	
21	861407	1	Turbo	
	3802091	1	Turbocharger, exch	Exchange unit
22	859834	1	Gasket	
23	859833	4	Stud	
24	861402	1	Bracket	
25	955894	3	Washer	
26	948645	4	Lock nut	
27	861401	1	Protecting casing	
28	3580979	1	Exhaust riser	
28A	982121	3	Plug	
29	861414	1	Gasket	
30	953045	4	Stud	
31	945408	4	Flange nut	
32	823494	1	Spacer sleeve	
33	965218	1	Screw	
34	961672	1	Clamp	
35	3580825	1	Connection pipe	
36	872531	1	Hose clamp	(961675)
37	861411	1	Air inlet	
38	961665	1	Hose clamp	
39	6646938	1	Hose	Oil filling-air filter.
40	961669	2	Hose clamp	
41	3580821	1	Hose	Sea water pump-heat exchanger.
42	961669	2	Hose clamp	
43	3581176	1	Hose	Heat exchanger-exhaust riser.
44	859814	1	Hose	
45	859815	1	Clamp	