



7584

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER AND THERMOSTAT WITH INSTALLATION COMPONENTS	02B-0150	
2		1	OIL COOLER	02B-0350	
2A	847108	1	Retainer		MO5312-
2B	949658	1	O-ring		(925061) MO5312-
2C	807182	1	Spacer sleeve		MO5312-
2D	838970	1	Brace		MO5312-
2E	955299	1	Screw		MO5312-
3		1	CIRCULATION PUMP WITH INSTALLATION COMPONENTS	02B-0250	
4		1		02B-0400	
5		1	INDUCTION- AND EXHAUST MANIFOLD WITH INSTALLATION COMPONENTS INDUCTION- AND EXHAUST MANIFOLD WITH INSTALLATION CO	02B-0600	
6	838314	1	Sea water pump	02B-0300	
7	829433	1	Companion flange		
8	947314	1	O-ring	IK	
9	955295	2	Screw		
10	941907	2	Spring washer		
11	949658	2	O-ring	IK	(925061)
12	838971	1	Tube		(846944) MO5312-
12A	847108	1	Retainer		MO5312-
12B	847107	1	Lock brace		MO5312-
12C	963545	2	Screw		
13	846046	1	Tube	02B-0150	
14	847105	1	Tube		
15	842697	1	Riser		
16	1542187	1	Gasket	IK	
17	925067	2	O-ring	IK 02B-0150	
18	842965	1	Tube	02B-0150	
19	955306	3	Screw		L = 80 MM
	955305	1	Screw		L = 75 MM
20	941907	4	Spring washer		
21	847107	1	Lock brace		
21A	963545	2	Screw		
21B	847108	1	Retainer		
22	949918	1	Drain cock		
23	846770	1	Tube	02B-0150	
					SEE GROUP 4A
23A	842913	1	Sealing ring	02B-0600	
23B	858986	1	Sealing ring		(842744)
				02B-0150	
23C	955271	2	Screw	02B-0600	
23D	941906	2	Spring washer	02B-0600	

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
29	955302	1	Screw		SEE GROUP 2A
30	947827	1	Clamp		
31	846339	1	Spacer sleeve		
32	955306	1	Screw		SEE GROUP 2A
33	965534	1	Bracket		
34	843075	1	Sleeve		
35	952635	1	Clamp		
36	955271	1	Screw		
37	955892	1	Washer		
38	955781	1	Nut		
39	941907	2	Spring washer		SEE GROUP 2A
40		X	WATER COOLED EXHAUST LINE		SEE GROUP 9
41		X	WATER COOLED EXHAUST MUFFLER		SEE GROUP 9
42		X	DRY EXHAUST LINE		SEE GROUP 9