



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	860513	1	Injection pump		
				02C-0925	
2	859601	1	Hub		
3	968971	1	O-ring		
4	953047	3	Stud		
5	191172	3	Washer		
6	945408	3	Flange nut		
7	860320	1	Feed pump		
8	3501530	1	Gasket		
9	941907	2	Spring washer		EARLY TYPE
10	946173	2	Flange screw		
11	840531	1	Fuel filter		
				02C-0800	
12	838583	1	Bracket		
13	965193	2	Screw		
14	843122	2	Spacer sleeve		
15	973083	2	Flange screw		
16	960148	2	Washer		EARLY TYPE
17	860447	1	Fuel pipe		
18	838722	1	Fuel pipe		
18A	969299	1	Hollow screw		
18B	11994	2	Gasket		
19	11994	2	Gasket		
20	969299	1	Hollow screw		
21	969011	4	Gasket		
22	25167	2	Hollow screw		
23	846780	1	Bracket		
24	952624	1	Clamp		
25	946544	1	Flange screw		ALT
	968855	1	Flange screw		ALT. SELF-TAPPING.
26	838666	1	Leak-off line		
27	947620	8	Gasket		
28	74033	4	Hollow screw		
29	859494	4	Injector		
	3803235	4	Injector, exch		Exchange unit
				02C-0860	
30	840402	4	Yoke		
31	924068	4	Stud		
32	945408	4	Flange nut		
33	956966	1	Ferrule		
34	956980	1	Nut		
35	121563	1	Clamp		
36	946544	1	Flange screw		
37	945407	1	Flange nut		
38		1	HOLLOW SCREW		INCLUDED IN COMPLETE FUEL INJECTION PUMP.
39	11994	2	Gasket		
40	838873	1	Delivery pipe		CYL NO. 1
41	838874	1	Delivery pipe		CYL NO. 2
42	838875	1	Delivery pipe		CYL NO. 3
43	838876	1	Delivery pipe		CYL NO. 4
44	470181	2	Clamp		2-PIPE

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
45	470183	2	Clamp		4-PIPE
46	829146	1	Pipe connection		
47	954337	2	Nipple		
48	954323	2	Cap nut		
49	860131	1	Air hose		
50	957171	4	Gasket		
51	74033	2	Hollow screw		
52	860021	1	Oil return pipe		
53	956980	1	Nut		
54	956966	1	Ferrule		
55	860028	1	Fuel hose		
56	845646	1	Fuel hose		
57	11994	2	Gasket		
58	969299	1	Hollow screw		