



7586

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER AND THERMOSTAT WITH INSTALLATION COMPONENTS	02B-0810	
2	838968	1	Oil cooler		(842589) MO 41832-
				02B-1400	
2A	847108	1	Retainer		MO 41832-
2B	807182	1	Spacer sleeve		MO 41832-
2C	838970	1	Brace		MO 41832-
2D	955299	1	Screw		MO 41832-
3		1	CIRCULATION PUMP WITH INSTALLATION COMPONENTS	02B-0910	
4		1	TURBO AND AIR FILTER WITH INSTALLATION COMPONENTS	02B-2010	
5		1	INDUCTION-AND EXHAUST MANIFOLD WITH INSTALLATION COMPONENTS	02B-2175	
6	842843	1	Water pump		
				02B-1250	
7	829433	1	Companion flange		
8	947314	1	O-ring	IK	
9	955295	2	Screw		
10	941907	2	Spring washer		
11	949658	2	O-ring		(925061)
12	847105	1	Tube		
13	838971	1	Tube		(846944) MO 41832-
13A	847108	1	Retainer		MO 41832-
13B	847107	2	Lock brace		MO 41832-
13C	963545	4	Screw		MO 41832-
13D	847108	1	Retainer		
14	82745	1	Tap		
15	842911	1	Brace		
16	955269	1	Screw		
17	955302	1	Screw		SEE GROUP 2A
18	947827	1	Clamp		
19	846339	1	Spacer sleeve		
20	955306	1	Screw		SEE GROUP 2A
21	965534	1	Bracket		
22	843075	1	Sleeve		
23	952635	1	Clamp		
24	955271	1	Screw		
25	955892	1	Washer		
26	955781	1	Nut		
27	941907	2	Spring washer		SEE GROUP 2A
28	949658	1	O-ring	IK	(925061)
29	1542187	1	Gasket		
30	842697	1	Riser		
31	941907	4	Spring washer		SEE GROUP 3
32	955305	4	Screw		SEE GROUP 3
33	842965	1	Tube		02B-2175
34	925067	1	O-ring	IK	02B-2175
35	846868	1	Coolant pipe		02B-0810
36	82745	1	Tap		02B-0810
37	961670	1	Hose clamp		02B-0810
38	843042	1	Gasket	IK	02B-2175
39	842614	1	Tube		
40	941906	2	Spring washer		
41	955276	2	Screw		
42	925065	1	O-ring	IK	

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
43		X	WATER COOLED EXHAUST LINE		SEE GROUP 9
44		X	WATER COOLED EXHAUST MUFFLER		SEE GROUP 9
45		X	DRY EXHAUST LINE		SEE GROUP 9