



4720

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	833323	1	Fuel pump		
				02C-0800	
2	942353	1	O-ring	IK	
3	940326	2	Screw		
4	941906	2	Spring washer		
5	840001	1	Hose		
6	25167	2	Hollow screw		
7	957178	4	Gasket	IK	
8	3875692	1	Injection pump		
				02C-0350	
9	3875387	1	Gasket	IK	
10	3875349	2	Stud		
11	955894	2	Washer		
12	955782	2	Nut		
13	840043	2	Injector		(3575688)
14	3875742	6	Yoke		
15	924066	4	Stud		
16	955782	4	Nut		
17	955894	4	Washer		
18	3875738	1	Delivery pipe		
19	3875739	1	Delivery pipe		
20	3877124	1	Clamp		SPEC 867417, 867418, 867419.
21	3877125	1	Washer		
21A	840105	2	Rubber sleeve		
22	955269	1	Screw		
23	955781	1	Nut		
24	3875693	1	Fuel filter		REPL BY 829992
25	240664	1	• Screw		
26	25534	1	• Gasket		
27	243463	1	• Plug		
28	243464	1	• Filter insert		
29	955317	2	Screw		
30	960148	2	Washer		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
31	960630	1	Plug		
32	957178	1	Gasket	IK	
33	3875737	1	Tube		
34	25167	1	Hollow screw		
35	957178	2	Gasket	IK	
36	3875740	1	Tube		
37	840212	1	Nipple		
38	957178	1	Gasket	IK	
39	3877089	2	Nipple		
40	957170	2	Gasket	IK	
41	942003	2	Hollow screw		
42	957171	4	Gasket		
43	942003	1	Hollow screw		
44	957171	2	Gasket		
45	74040	1	Hollow screw		
46	957175	2	Gasket	IK	
47	840264	1	Fuel hose		(840015) REPL BY 840264
48	840094	1	Check valve		INCLUDED IN FUEL INJECTION PUMP.
49	957175	2	Gasket	IK	
50	829744	2	Hose connection		
51		2	· NUT		
52	833922	2	Nipple		
53	840263	1	Fuel hose		(807074) REPL BY 840263
54	25167	1	Hollow screw		
55	957178	2	Gasket	IK	
56	828340	1	Tank		(833863) SEE GROUP 9
57	833454	1	· Fuel pump		SEE GROUP 9
58		1	WATER SEPARATOR	02C-1000	