



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	840006	1			RATIO 1:1
2	827617	1	· Companion flange		
3	959223	4	· Screw		
4	941907	4	· Spring washer		
5	834036	1	· Cover		
6	852156	1	· Gasket	IK	
7	958878	1	· Sealing ring	IK	
8	914472	1	· Lock ring		
10	19578	1	· Ball bearing		
12	914540	1	· Lock ring		
13	914517	1	· Lock ring		
14	827317	1	· Plug		
15	955997	1	· O-ring	IK	
16	827583	1	· Screw		
17	827665	1	· Washer		
18	827315	1	· Washer		
19	25930	X	· Adjusting washer		TH = 0,10 MM
	120073	X	· Shim		TH = 0,50 MM
21	827309	1	· Gear		
22	944013	1	· Key		
23	181268	4	· Needle bearing		
24	813939	2	· Spacer ring		
25	827590	1	· Sleeve		
26	827310	1	· Gear		
27	914540	1	· Lock ring		
28	19578	1	· Ball bearing		
29	914472	1	· Lock ring		
30	827589	1	· Axle shaft		
31	850761	1	· Pin		
33	813941	1	· Spacer ring		
34	814030	1	· Lock ring		
35	827314	4	· Bushing		
36	183366	4	· Needle bearing		
37	827312	2	· Gear		
38	834008	2	· Spacer sleeve		
39	951931	2	· Tensioning din		
40	827313	2	· Planet shaft		
41	827816	1	· Planetary housing		
42	960628	1	· Plug		
43	834452	1	· Gasket	IK	
44	925063	1	· O-ring	IK	

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
45	941338	X	· Locking wire		L = 300 MM, EARLY TYPE
46	839136	2	· Spring		EARLY TYPE
47	60309	2	· Ball		EARLY TYPE
48	955272	4	· Screw		
49	839505	1	· Bearing housing		
50	814184	1	· Spring		
51	814603	1	· Dog		
53	951924	1	· Tensioning din		
54	942871	1	· Pin		
55	897816	1	· Eccentric piston		
			· Bulletin P-44-1-7	P-44-1-7-EN	Shift mechanism, eccentric piston
56	897871	X	· Adjusting washer		TH = 0,20 MM
57	897711	1	· Screw		
59	833560	1	· Oil dipstick		
62	15305	1	· Gasket	IK	
64	827307	1	· Bearing housing		
65	941907	4	· Spring washer		
66	955297	4	· Screw		
67	955073	1	· Plug		EARLY TYPE
68	914462	1	· Lock ring		
69	181286	1	· Ball bearing		
70	914533	1	· Snap ring		
71	958863	1	· Sealing ring	IK	
72	827901	1	· Companion flange		
73	192211	1	· Plug		
74	827889	1	· Gasket	IK	
75	875576	1	Gasket kit		SEE GROUP 10