



6306

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|-----------------------|-------------|-----------------------------------|
| 1 | 851610 | 1 | Reversing gear | | RATIO 2,37:1 |
| 2 | 852523 | 1 | • Housing | | (852352) |
| 3 | 852524 | 1 | • Cover | | (851614) |
| 4 | 949962 | 1 | • O-ring | IK | |
| 5 | 851754 | 1 | • Oil filler cap | | |
| 6 | 925254 | 1 | • O-ring | IK | |
| 7 | 946671 | 4 | • Flange screw | | (948336) |
| 8 | 851616 | 1 | • Gear set | | |
| 9 | 851621 | 1 | • Guide disc | | |
| 10 | 851619 | 1 | • Bearing box | | |
| 11 | 181302 | 1 | • Cup | | |
| 12 | 181301 | 1 | • Cone | | |
| 13 | 183750 | 1 | • Cup | | |
| 14 | 183752 | 1 | • Cone | | |
| 15 | 852485 | 1 | • Lock nut | | |
| 16 | 851755 | 1 | • Sealing ring | IK | |
| 17 | 925093 | 1 | • O-ring | IK | |
| 18 | 940101 | 6 | • Screw | | |
| 19 | 851622 | X | • Adjusting washer | | TH = 0,10 MM |
| | 851623 | X | • Adjusting washer | | TH = 0,15 MM |
| | 851624 | X | • Adjusting washer | | TH = 0,35 MM |
| 20 | 851756 | 2 | • Bearing | | |
| 21 | 852190 | 2 | • Lock ring | | |
| 22 | 851626 | 1 | • Sliding sleeve | | |
| 23 | 852527 | 1 | • Shaft | | |
| 24 | 84219 | X | • Adjusting washer | | TH = 0,10 MM |
| | 949776 | X | • Adjusting washer | | TH = 0,15 MM |
| | 84218 | X | • Spacer | | TH = 0,35 MM |
| 25 | 852079 | 2 | • Lock washer | | |
| 26 | 852311 | 2 | • Washer | | |
| 27 | 852317 | 2 | • Washer | | |
| 28 | 852213 | 2 | • Disc spring | | |
| 29 | 852080 | 6 | • Disc spring | | |
| 30 | 851629 | 4 | • Lock ring half | | |
| 31 | 851757 | 2 | • Needle bearing | | |
| 32 | 851661 | 1 | • Shift mechanism | | |
| 33 | 851662 | 1 | • • Bearing housing | | |
| 34 | 897816 | 1 | • • Eccentric piston | | |
| | | | • • Bulletin P-44-1-7 | P-44-1-7-EN | Shift mechanism, eccentric piston |
| 35 | 851664 | 1 | • • Dog | | |
| 36 | 925065 | 1 | • • O-ring | IK | |
| 37 | 814184 | 1 | • • Spring | | |
| 38 | 897711 | 1 | • • Screw | | |
| 39 | 897871 | X | • • Adjusting washer | | TH = 0,20 MM |
| 40 | 958838 | 1 | • • Sealing ring | IK | |
| 41 | 942871 | 1 | • • Pin | | |
| 42 | 951924 | 1 | • • Tensioning din | | |
| 43 | 955296 | 2 | • Screw | | |
| 44 | 941907 | 2 | • Spring washer | | |
| 45 | 852319 | 1 | • Gear set | | |
| 46 | | 2 | • • GEAR | | |
| 47 | | 4 | • • CUP SPRING | | |
| 48 | | 18 | • • OUTER DISC | | |
| 49 | | 17 | • • INNER DISC | | |
| 50 | | 2 | • • THRUST WASHER | | |
| 51 | | 1 | • • ADJUSTING SCREW | | |
| 52 | | 1 | • • BUSHING | | |
| 53 | 183518 | 1 | • Bearing | | |
| 54 | 851705 | X | • Adjusting washer | | TH = 0,10 MM |
| | 851706 | X | • Adjusting washer | | TH = 0,15 MM |
| | 851707 | X | • Adjusting washer | | TH = 0,35 MM |

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|--------------------|----------|--------------------|
| 55 | 181662 | 1 | • Cup | | |
| 56 | 181305 | 1 | • Cone | | |
| 57 | 851702 | X | • Adjusting washer | | TH = 0,10 MM |
| | 851703 | X | • Adjusting washer | | TH = 0,15 MM |
| | 851704 | X | • Adjusting washer | | TH = 0,35 MM |
| 58 | 851640 | 1 | • Bearing cover | | |
| 59 | 87655 | X | • Adjusting washer | | TH = 0,10 MM |
| | 191840 | X | • Adjusting washer | | TH = 0,15 MM |
| | 87654 | X | • Spacer | | TH = 0,35 MM |
| | 941835 | X | • Adjusting washer | | TH = 0,5 MM |
| 60 | 960629 | 1 | • Plug | | |
| 61 | 947084 | 1 | • Gasket | IK | |
| 62 | 946671 | 4 | • Flange screw | | (948336) |
| 63 | 925256 | 1 | • O-ring | IK | |
| 64 | 851928 | 1 | • Bearing housing | | |
| 65 | 852163 | 1 | • Oil cooler | | |
| 66 | 925057 | 2 | • Rubber ring | IK | |
| 67 | 852733 | 1 | • Pipe connection | | (852157) |
| 68 | 955278 | 1 | • Screw | | |
| 69 | 949750 | 1 | • O-ring | IK | |
| 70 | 941906 | 1 | • Spring washer | | |
| 71 | 851974 | 1 | • Collet | | |
| 72 | 181302 | 2 | • Cup | | |
| 73 | 181301 | 2 | • Cone | | |
| 74 | 852528 | 1 | • Sealing ring | IK | |
| 75 | 925262 | 1 | • O-ring | IK | |
| 76 | 946470 | 2 | • Flange screw | | L = 35 MM |
| | 947760 | 2 | • Flange screw | | L = 40 MM |
| 77 | 965180 | 2 | • Flange screw | | L = 60 MM (965217) |
| 78 | 925062 | 1 | • O-ring | IK | |
| 78A | 944138 | 1 | • Sealing ring | IK | |
| 79 | 852076 | 1 | • Companion flange | | |
| 80 | 947855 | 1 | • Lock nut | | |
| 81 | 852168 | 1 | • Bracket | | |
| 82 | 819067 | 1 | • Brace | | |
| 83 | 819068 | 1 | • Washer | | |
| 84 | 940090 | 2 | • Washer | | |
| 85 | 955246 | 2 | • Screw | | |
| 86 | 946577 | 2 | • Lock nut | | |
| 87 | 852363 | 1 | • Lever | | |
| 88 | 955270 | 2 | • Screw | | |
| 89 | 955948 | 2 | • Lock washer | | |
| 90 | 955781 | 2 | • Nut | | |
| 91 | 833462 | 1 | • Cube | | PZ-7905 |
| 91 | 833462 | 1 | • Cube | | PZ 7906- |
| 92 | 955892 | 1 | • Washer | | |
| 93 | 17276 | 1 | • Cotter pin | | |
| 94 | 852314 | 1 | • Oil dipstick | | |
| 95 | 925054 | 1 | • O-ring | | |
| 96 | 852228 | 1 | • Tube | | |
| 97 | 852229 | 1 | • Cap | | |
| 98 | 925055 | 1 | • O-ring | IK | |
| 99 | 956063 | 1 | • Screw | | |
| 100 | 955891 | 1 | • Washer | | |
| | 875704 | 1 | Gasket kit | | SEE GROUP 10A |