



4408

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER AND THERMOSTAT WITH INSTALLATION COMPONENTS	02B-0650	
2		1	CIRCULATION PUMP AND DRIVE DEVICE WITH INSTALLATION COMPONENTS	02B-1350	
3		1	OIL COOLER AND INSTALLATION COMPONENTS	02B-0900	
4		1	SEA WATER PUMP AND INSTALLATION COMPONENTS	02B-1100	
5		1	BILGE PUMP AND INSTALLATION COMPONENTS		SEE GROUP 9
6		1	TURBO AND AIR FILTER WITH INSTALLATION COMPONENTS	02B-1700	
7		1	INDUCTION MANIFOLD AND AFTERCOOLER WITH INSTALLATION COMPONENTS	02B-2400	
8		1	EXHAUST MANIFOLD AND INSTALLATION COMPONENTS	02B-2500	
9	836803	1	Tube	02B-1100	
10	836778	2	Gasket		
11	950060	4	Screw		
12	836806	1	Tube		
13	13430	X	Rubber hose		L = 80 MM
14	943476	10	Hose clamp		
15	801163	1	Hose attachment		
16	837143	1	Bracket		
17	943717	1	Clamp		
18	950059	1	Screw		
19	955826	1	Nut		
20	836858	1	Coolant pipe		
21	801163	1	Hose attachment		
22	830534	1	Hose		
23	943476	2	Hose clamp		
24	836771	1	Tube		REVERSE GEAR TWIN DISC.
25	801308	1	Hose attachment		
26	801157	1	Elbow nipple		
27	837144	1	Tube	02B-2500	
29	801157	1	Elbow nipple	02B-0650	
30	819815	1	Pressure gauge kit		SEE GROUP 9
31		1	SEA WATER INTAKE		SEE GROUP 9