



3636

**TURBOCHARGER AND AIR FILTER WITH INSTALLATION COMPONENTS:
AQD70BL**

02B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	836968	1			REPLACED BY 1EA 837555, 1EA 867553, 2EA 955295, 2EA 941907, 1EA 837554, 4EA 924079, 1EA 842378, 1EA 466327, 2EA 961672, 1EA 837557, 1EA 837556, 1EA 837868, 1EA 837810.
	837555	1	Turbo	02B-1750	
				02B-1800	
2	421324	1	Gasket	IK	INCLUDED IN TURBO COMPRESSOR.
3	943883	4	Stud		
4	955895	4	Washer		
5	942336	4	Spring washer		
6	940183	4	Nut		
7	471098	1	Tube		
8	957178	2	Gasket	IK	
9	25167	1	Hollow screw		
13	944454	1	Hollow screw		
14	957181	1	Gasket		
15	957178	1	Gasket		
16	952625	1	Clamp		
17	950045	1	Screw		
18	424288	1	Bracket		
19	471099	1	Tube		
20	836181	1	Gasket		INCLUDED IN TURBO COMPRESSOR.
21	955295	2	Screw		
22	940135	2	Screw		
23	941907	4	Spring washer		
24	469482	1	O-ring	IK	SEE GROUP 2A
25	940113	1	Screw		
26	941907	1	Spring washer		
27	945081	1	Clamp		
28	836766	1	Tube		
29	953237	4	Stud		
30	941907	4	Spring washer		
31	955826	4	Nut		
34	836767	1	Gasket		
35	945649	1	Hose		
36	943480	2	Clamp		
37	836386	1	Tube		
38	191157	1	Hollow screw		
39	957185	2	Gasket	IK	
40	420171	1	Gasket		
41	955524	2	Screw		
42	941907	2	Spring washer		
43	471093	1	Coolant pipe		
44	191158	1	Hollow screw		
45	82745	2	Tap		
46	191158	1	Hollow screw		
47	957185	4	Gasket	IK	
48	837047	1	Air filter		
49	837049	1	· Insert		
50	837050	1	· Gasket		
51	824303	1	Spacer ring		
52	943481	1	Hose clamp		
53	955523	1	Screw		
54	941907	1	Spring washer		
55	940186	1	Screw, SCREW RESILIENT WASHER	02B-2400	
56	941907	1	Spring washer	02B-2400	
57	955826	1	Nut, NUT EXHAUST ELBOW	02B-2400	
58		1		02B-2600	