



3496

REF	PART NO.	QTY	DESCRIPTION		NOTES
1	466769	2	Cylinder head		
2	421011	6	· Valve seat		STD D
	421316	6	· Valve seat		0,20 MM O.S
3	466266	6	· Valve seat		STD D
	466307	6	· Valve seat		0,20 MM O.S
4	466386	12	· Valve guide		
5	469205	6	· O-ring	IK	
6	466284	6	· Spray sleeve		
7	192426	4	· Plug		
8	467367	4	· Plug		
9	469328	4	· Gasket	IK	
10	466230	4	· Plug		
11	420166	4	· Gasket	IK	
12	421016	6	Inlet valve		
13	421208	6	Exhaust valve		
14	421374	12	Valve spring		
15			SPRING		
16	421295	12	Washer		
17	402418	24	Valve collet		
18	469365	12	Valve cap		
19	469456	12	Protecting ring	IK	
20	421416	6	Bearing bracket		
21	420270	4	Stud		
22	955540	8	Screw		
23	942336	8	Spring washer		
24	421019	2	Shaft		
25	946778	4	· Cap plug		
26	422063	12	Rocker arm		
27	422066	12	· Bushing		
28	423058	12	· Ball stud		
29	940175	12	· Nut		
30	421173	4	Spring		
31	421172	4	Spring		
32	914459	4	Lock ring		
33	275525	2	Gasket kit		
34	422414	12	· Sealing ring	IK	D = 32 MM
	466421	16	· Sealing ring	IK	D = 16 MM
	422413	2	· Sealing ring	IK	D = 11 MM
35	421218	20	Screw		L = 168 MM
36	466764	6	Screw		L = 118 MM
37	421063	1	Cover		
38	421065	1	Cover		
39	424341	4	Cap nut		
40	469846	4	Sealing ring	IK	
41	914449	4	Lock ring		
42	421066	2	Gasket	IK	
43	420292	1	Oil filler cap		
	407173	1	Cover		USED WHEN OIL PAN 822967 IS INSTALLED.
44	940096	1	Gasket	IK	
45	949020	4	Pin		