



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	243625	1			
2	243773	1		02C-1100	
4	240072	1		02C-1350	REPL BY 243083
	243083	1	· Feed pump	02C-1350	
5		1	· HOUSING		
6	239982	6	· Tappet		
7	240779	6	· · Bolt		
8	240780	6	· · Bushing		
9	240781	6	· · Roller		
10	238379	6	· · Plate		
11	244685	6	· Spring disc		
12	847277	6	· Spring		
13	239984	6	· Spring disc		
14	240782	6	· Control sleeve		
15	239991	6	· Cover		
16	241677	6	· Washer		
17	239990	6	· Lock ring		
18	240003	6	· Spacer ring		
19	240002	6	· O-ring		
20	240424	X	· Gasket		TH = 0,15 MM
	240004	X	· Gasket		TH = 0,40 MM
	240005	X	· Gasket		TH = 0,50 MM
	240006	X	· Gasket		TH = 0,60 MM
	240007	X	· Gasket		TH = 0,70 MM
	240008	X	· Gasket		TH = 0,80 MM
21	243741	6	· Bushing		
22	239989	6	· O-ring		
23	240422	6	· O-ring		
24	239988	6	· Pump element		
25	240783	6	· Delivery valve		
26	239993	6	· Gasket		
27	238309	6	· Spring		
29	240001	6	· Gasket		
30	243771	6	· Delivery valve retai		
31A	243743	12	· Washer		
32	240010	12	· Screw		
33	941908	12	· Spring washer		
34	955783	12	· Nut		
35	240011	1	· Cover		
36	956209	2	· Screw		
37	18891	2	· Lock washer		
38	240907	1	· Control rod		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
39	240014	2	· Guide sleeve		
40	244008	1	· Lock pin		
41	240015	1	· Bushing		
42	238663	6	· Plug		
43	238312	X	· Adjusting washer		TH = 0,3 MM
	241734	X	· Adjusting washer		TH = 0,5 MM
	238314	X	· Adjusting washer		TH = 1,0 MM
44	240429	6	· Plug		
45	243263	1	· Plug		LATE TYPE
46	240017	1	· Gasket		LATE TYPE
47	240789	1	· Camshaft		
48	240426	1	· Bearing		
49	240427	2	· Screw		
50	941906	2	· Spring washer		
51	240023	1	· Roller bearing		
52	240022	1	· Sealing ring		
53	243299	1	· O-ring		
54	240024	X	· Adjusting washer		TH = 0,10 MM
	240025	X	· Adjusting washer		TH = 0,12 MM
	240026	X	· Adjusting washer		TH = 0,14 MM
	240027	X	· Adjusting washer		TH = 0,16 MM
	240028	X	· Adjusting washer		TH = 0,18 MM
	240029	X	· Adjusting washer		TH = 0,30 MM
	240030	X	· Adjusting washer		TH = 0,50 MM
55	240021	1	· Cover		
56	956094	4	· Screw		
57	941906	4	· Spring washer		
58	955806	1	· Nut		
59	941913	1	· Spring washer		
60	35168	1	· Key		
61	240023	1	· Roller bearing		
62	240032	1	· Ring		
63	240033	X	· Adjusting washer		TH = 1,2 MM
	240034	X	· Adjusting washer		TH = 1,5 MM
	240035	X	· Adjusting washer		TH = 1,8 MM
	240036	X	· Adjusting washer		TH = 2,0 MM
64	240947	1	· Cover		
65	240948	1	· Gasket		
66	956205	12	· Screw		
67	239896	1	· Gasket		
68	130673	3	· Stud		
	955781	3	· Nut		
70	941906	3	Spring washer		
71	241647	1	· Setting indicator		
72	100101	2	· Screw		
73	941906	2	· Spring washer		