



8472

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER AND THERMOSTAT WITH INSTALLATION COMPONENTS	02B-0450	
2		1	CIRCULATION PUMP AND DRIVE DEVICE WITH INSTALLATION COMPONENTS	02B-1250	
3		1	OIL COOLER AND INSTALLATION COMPONENTS	02B-0750	
4		1	SEA WATER PUMP AND INSTALLATION COMPONENTS	02B-1000	
5		1	BILGE PUMP AND INSTALLATION COMPONENTS		SEE GROUP 9
6		1	TURBO AND AIR FILTER WITH INSTALLATION COMPONENTS	02B-1500	
7		1	INLET MANIFOLD AND AFTER COOLER WITH INSTALLATION COMPONENTS	02B-2100	
8		1	EXHAUST MANIFOLD WITH INSTALLATION COMPONENTS	02B-2150	
9		1	OIL COOLER, REV. GEAR		SEE GROUP 4
10	843020	1	Tube		
11	836778	1	Gasket		
12	950060	2	Screw		
13	940162	1	Screw		SEE GROUP 2A
14	942336	1	Spring washer		SEE GROUP 2A
15	192134	1	Plug		
16	836759	1	Hose attachment		
17	942334	1	Hose attachment		
18	192134	1	Plug		
19	942707	X	Rubber hose		L = 110 MM. REVERSE GEAR BORG WARNER.
	942707	X	Rubber hose		L = 180 MM. REVERSE GEAR SCG.
	942707	X	Rubber hose		L = 170 MM. REVERSE GEAR TWIN DISC.
20	943475	2	Hose clamp		
21	942707	X	Rubber hose		L = 90 MM
22	837670	1	Hose hook		
23	943476	4	Hose clamp		
24	819815	1	Pressure gauge kit		SEE GROUP 9
25		1	SEA WATER INTAKE		SEE GROUP 9