



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	843026	1	Injection pump		
2	837736	1	• Centrifugal governor		
				02C-1050	
3	837738	1	• • Smoke limiter		
				02C-1200	
4	243083	1	• Feed pump		
				02C-1350	
5		1	• PUMP HOUSING		
6	239982	6	• • Tappet		
7	240779	6	• • Bolt		
8	240780	6	• • Bushing		
9	240781	6	• • Roller		
10	238379	6	• • Plate		
11	244685	6	• Spring disc		
12	847277	6	• Spring		
13	239984	6	• Spring disc		
14	240782	6	• Control sleeve		
15	239991	6	• Cover		
16	239990	6	• Lock ring		
17	240003	6	• Spacer ring		
18	240002	6	• O-ring		
19	240424	X	• Gasket		TH = 0,15 MM
	240004	X	• Gasket		TH = 0,40 MM
	240005	X	• Gasket		TH = 0,50 MM
	240006	X	• Gasket		TH = 0,60 MM
	240007	X	• Gasket		TH = 0,70 MM
	240008	X	• Gasket		TH = 0,80 MM
20	243741	6	• Bushing		
21	241677	6	• Washer		
22	240422	12	• O-ring		
23	837733	6	• Pump element		
24	243754	6	• Delivery valve		
25	239993	6	• Gasket		
26	240969	6	• Spring		
27	240001	6	• Gasket		
28	243742	6	• Delivery valve retai		
29	243743	12	• Washer		
30	240010	12	• Screw		
31	941908	12	• Spring washer		
32	955783	12	• Nut		
33	240011	1	• Cover		
34	956209	2	• Screw		
35	18891	2	• Lock washer		
36	241746	1	• Control rod		
37	240014	2	• Guide sleeve		
38	244008	1	• Lock pin		
39	240015	1	• Bushing		
40	240971	6	• Plug		
41	240972	X	• Washer		TH = 0,20 MM
	240973	X	• Washer		TH = 0,50 MM
42	837735	6	• Plug		
43	18836	6	• Gasket		
44	243263	1	• Plug		
45	240017	1	• Gasket		
46	240789	1	• Camshaft		
47	240426	1	• Bearing		
48	240427	2	• Screw		
49	941906	2	• Spring washer		
50	240023	2	• Roller bearing		
51	240022	1	• Sealing ring		
52	243299	1	• O-ring		
53	240024	X	• Adjusting washer		TH = 0,10 MM
	240025	X	• Adjusting washer		TH = 0,12 MM

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
53	240026	X	· Adjusting washer		TH = 0,14 MM
	240027	X	· Adjusting washer		TH = 0,16 MM
	240028	X	· Adjusting washer		TH = 0,18 MM
	240029	X	· Adjusting washer		TH = 0,30 MM
	240030	X	· Adjusting washer		TH = 0,50 MM
	238312	X	· Adjusting washer		
54	240021	1	· Cover		
55	956094	4	· Screw		
56	941906	4	· Spring washer		
57	955806	1	· Nut		
58	941913	1	· Spring washer		
59	35168	1	· Key		
60	240032	1	· Ring		
61	240033	X	· Adjusting washer		TH = 1,2 MM
	240034	X	· Adjusting washer		TH = 1,5 MM
	240035	X	· Adjusting washer		TH = 1,8 MM
	240036	X	· Adjusting washer		TH = 2,0 MM
62	240947	1	· Cover		
63	240948	1	· Gasket		
64	956205	12	· Screw		
65	239896	1	· Gasket		
66	130673	3	· Stud		
67	955781	3	· Nut		
68	941906	3	· Spring washer		