



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	ALTERNATOR AND INSTALLATION COMPONENTS		12V38A
				030-0700	
		1	ALTERNATOR AND INSTALLATION COMPONENTS		24V25A
				030-0700	
		1	ALTERNATOR AND INSTALLATION COMPONENTS		24V60A
				030-0725	
2	843067	1	Instrument panel		12V
				030-1850	
2	843076	1	Instrument panel		24V
				030-1850	
3	843511	1	Starter motor		12V REPL BY 847306. MO 12338/XXXX-.
				030-1450	
	843510	1	Starter motor		24V REPL BY 847307. MO 12338/XXXX-.
				030-1450	
	847306	1	Starter motor		12V
				030-1515	
	847307	1	Starter motor		24V
				030-1525	
8	842345	1	Bracket		
9	821540	1	Spacer sleeve		
10	955536	1	Screw		L = 45 MM
	940114	2	Screw		L = 22 MM
11	942336	3	Spring washer		
12	837791	2	Clutch housing		REPL BY 1 PC 845838 , 1 PC 955129
13	955524	3	Screw		
14	941907	3	Spring washer		
15	837829	1	Terminal block		
16	88578	1	Fuse box		
17	943905	2	Fuse		25A
18	837796	4	Screw		
19	17602	8	Nut		
20	941616	4	Screw		
21	77796	2	Fuse		50A
	239148	2	Fuse		80A
22	1501832	1	Relay		12V38A (839367)
	1501833	1	Relay		24V60A,24V25A (839434)
23	941269	2	Cable grommet		
24			CABLE HOLDER		
25	950144	2	Screw		
26	120265	2	Washer		
27	955512	1	Screw		
28	941906	1	Spring washer		
29	842453	1	Cable trunk		ENGINE
	837836	1	Cable trunk		CONNECTOR, INSTRUMENT PANEL.

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
29	843334	1	Cable trunk		24V25A. ALTERNATOR, STARTER, CONNECTING SCREW.
29	843311	1	Cable trunk		24V60A
30	825738	X	Cable trunk		L = 2500 MM
	820419	X	Cable		L = 7000 MM
31	827150	1	Temperature sensor		
32	822858	1	Thermo monitor		
33	843231	1	Oil pressure sensor		
34	843812	1	Switch, SWITCH NIPPLE		STOP
35	180002	1	Fitting		(942490)
36	880281	1	Pressure monitor, OIL PRESSURE SENDER HOUR INDICATOR		
37	180002	1	Fitting		
38	354671	1	Tachometer sensor		SEE GROUP 2A (837783)
39	925059	1	O-ring	IK	SEE GROUP 2A
40	837781	1	Pressure sensor, PRESSURE SENSOR REVERSE GEAR		SEE GROUP 4A
	837782	1	Pressure sensor		SEE GROUP 2B
41	957181	2	Gasket		
42	837993	1	Instrument panel		12V. -INSTRUMENT PANEL FOR HOUR INDICATOR AND EXTRA ALARM DEVICE.
				030-1650	
	837994	1	Instrument panel		24V. -INSTRUMENT PANEL FOR HOUR INDICATOR AND EXTRA ALARM DEVICE.
				030-1650	
43	837995	1	Instrument panel		12V. INSTRUMENT PANEL FOR TANK GAUGE AND RUDDER ANGEL INDICATOR
				030-1700	
	837996	1	Instrument panel		24V. INSTRUMENT PANEL FOR TANK GAUGE AND RUDDER ANGEL INDICATOR
				030-1700	
44	837772	1	Rudder position sens		
45	837999	1	Tank sensor		
46	956078	4	Screw		L = 16 MM
	956081	1	Screw		L = 25 MM
47	834481	5	Gasket		
48	89865	1	Gasket		
49	834480	1	Flange		
50			STOP SOLENOID AND INSTALLATION COMPONENTS		SEE GROUP 2D