


TAMD70D,AQD70D



TAMD70D,AQD70D

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	843511	1	Starter motor		12V REPL BY 847306
				030-1450	
	843510	1	Starter motor		24V REPL BY 847307
				030-1450	
	847306	1	Starter motor		12V LATER PROD
				030-1515	
	847307	1	Starter motor		24V LATER PROD
				030-1525	
2	953486	3	Stud		
3	955827	3	Nut		
4	942336	3	Spring washer		
5		1	ALTERNATOR AND INSTALLATION COMPONENTS		12V38A,24V25A
				030-0800	
		1	ALTERNATOR AND INSTALLATION COMPONENTS		24V60A
				030-1050	
6		1	CHARGING RELAY AND INSTALLATION COMPONENTS		12V38A,24V25A
				030-0800	
	823766	1	Charge regulator		24V60A
				030-1350	
7	843195	1	Cable trunk		12V38A,24V25A. ALTERNATOR,STARTER,FUSE, CHARGING RELAY.
	843209	1	Cable trunk		24V60A. ALTERNATOR,STARTER,FUSE, CHARGING RELAY.
8	941265	1	• Cable grommet		
9		1	STOP SOLENOID AND INSTALLATION COMPONENTS		SEE GROUP 2D
10	837821	1	Cable trunk		
11	941265	1	• Cable grommet		
12	827150	1	Temperature sensor		
13	11996	1	Gasket		
14	843231	1	Oil pressure sensor		
15	881348	1	Pressure switch		STOP
16	942490	1	T-nipple		
17	880281	1	Pressure monitor		
18	180002	1	Fitting		
19	822858	1	Thermo monitor		
20	837825	1	Bracket		
21	940135	3	Screw		
22	941907	3	Spring washer		
23	837791	2	Clutch housing		MO 12338/XXXX-.
24	955524	3	Screw		
25	941907	3	Spring washer		
26	837829	1	Terminal block		
27	88578	1	Fuse box		
28	943905	2	Fuse		
29	837796	4	Screw		
30	17602	8	Nut		
31	77796	2	Fuse		50A
	239148	2	Fuse		80A
32	941616	4	Screw		
33		1	FLANGE		SEE GROUP 2B
34		1	FLAME GLOW PLUG		SEE GROUP 2C
35		1	SOLENOID VALVE		SEE GROUP 2C
36	956571	2	Screw		
37	941907	2	Spring washer		

TAMD70D,AQD70D

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
38	960141	2	Washer		
39	837372	2	Spacer sleeve		
40	837369	2	Bushing		
41	837335	1	Clutch housing		
42	823617	1	Cover		
43	950047	4	Screw		
44	941906	6	Spring washer		
45	844486	1	Timer relay		12V
	837344	1	Resistor		24V
46	950044	2	Screw		
47	870670	3	Relay		12V
	870451	3	Relay		24V
48	950009	4	Screw		
49	942558	1	Terminal block		
50	88578	1	Fuse box		
51	943905	2	Fuse		25A
52	950011	4	Screw		
53	842390	1	Bridge connector		
54	823759	2	Cable grommet		
55	837822	1	Cable trunk		
56	354671	1	Tachometer sensor		SEE GROUP 2A
57	925059	1	O-ring		SEE GROUP 2A
58		1	OIL PRESSURE SENSOR		SEE GROUP 4A
59		1	AIR PRESSURE SENSOR		SEE GROUP 2B
60	837836	1	Cable trunk		CONNECTOR,INSTRUMENT PANEL.
61	941265	2	· Cable grommet		
62	844443	1	Instrument panel		12V ALT
				030-1900	
	844444	1			24V ALT
				030-1900	
63	837820	1	Instrument panel		12V ALT
				030-1600	
	837819	1	Instrument panel		24V ALT
				030-1600	
64	837993	1	Instrument panel		12V. -INSTRUMENT PANEL FOR HOUR INDICATOR AND EXTRA ALARM DEVICE.
				030-1650	
	837994	1	Instrument panel		24V. -INSTRUMENT PANEL FOR HOUR INDICATOR AND EXTRA ALARM DEVICE.
				030-1650	
65	837995	1	Instrument panel		12V. INSTRUMENT PANEL FOR TANK GAUGE AND RUDDER ANGEL INDICATOR
				030-1700	
	837996	1	Instrument panel		24V. INSTRUMENT PANEL FOR TANK GAUGE AND RUDDER ANGEL INDICATOR
				030-1700	
66	825738	X	Cable trunk		L = 2500 MM
	820419	X	Cable		L = 7000 MM
	839180	X	Cable		L = 5000 MM. USE TOGETHER WITH INSTR.PANEL 844443 AND 844444. ND 844444
	839180	X	Cable		L = 7000 MM. USE TOGETHER WITH INSTR.PANEL 844443 AND 844444. ND 844444
67	837999	1	Tank sensor		
68	956078	4	· Screw		L = 16 MM
	956081	1	· Screw		L = 25 MM
69	834481	5	· Gasket		
70	89865	1	· Gasket		
71	834480	1	· Flange		
72	837772	1	Rudder position sens		
73	837374	1	Sign		
74		1	CABLE HOLDERS		

