



6760

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	863260	1	Inlet pipe		
2	469830	6	Rubber ring	IK	
3	955529	11	Screw		
4	941907	11	Spring washer		
5	191026	1	Plug		
6	836841	1	Exhaust pipe	02B-1790	
7	467367	12	· Plug		
8	469328	12	· Gasket		
9	470534	6	Gasket		
10	822575	6	Sealing ring		
11	942547	4	Screw		L = 133 MM
12	192058	2	Screw		L = 152 MM. STANDARD FUEL PIPE IS INSTALLED
	959800	1	Screw		L = 178 MM. WHEN DOUBLE SHEATED FUEL PIPES ARE INSTALLED.
13	941252	5	Screw		L = 171 MM
	102040	1	Screw		L = 190 MM
14	942336	12	Spring washer		
15	949918	2	Drain cock		
16	822546	1	Bracket		SEE GROUP 2C
17	822593	1	End cover		
18	862586	1	Gasket		
19	822575	1	Sealing ring		
20	940115	3	Screw		L = 25 MM
	955535	2	Screw		L = 32 MM
	955539	1	Screw		L = 64 MM
21	942336	6	Spring washer		
22	470464	1	Hose		
23	943480	2	Clamp		
24	844659	2	Attaching plate		SEE GROUP 2C
25	912130	2	Spacer ring		