



6656

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	847308	1	Starter motor		24V
				030-0985	
2		1	STARTER COVER WITH INSTALLATION COMPONENTS	030-0475	
3		1	OIL AND FUEL SUPERVISION WITH INSTALLATION COMPONENTS	030-0590	
4		1	COOLANT MONITOR WITH INSTALLATION COMPONENTS	030-0725	
5		1	ELECTRICAL BOX WITH INSTALLATION COMPONENTS	030-0800	
6		1	EMERGENCY STOP	030-0900	
7		1	STOP SOLENOID WITH INSTALLATION COMPONENTS		SEE GROUP 2D
8	942336	3	Spring washer		
9	955827	3	Nut		
11	843102	1	Box		
12	843103	1	Attaching plate		
13	354671	1	Tachometer sensor		
14	925059	1	O-ring		
15	956059	4	Screw		
16	941904	4	Spring washer		
17	822327	1	Cable union		
18	880243	1	Nut		
19		X	CABLES		ACC. TO CLASSIFICATION.
				030-1000	
20	953486	3	Stud		
21			CABLE HOLDERS		
22	955271	1	Screw		
23	955272	1	Screw		
24	941906	3	Spring washer		
25	955781	2	Nut		
26	940133	1	Screw		
27	942336	1	Spring washer		
28	959789	1	Screw		
29	844375	1	Sleeve		
30	952628	X	Clamp		
	952631	X	Clamp		
31	956092	X	Screw		
32	941906	X	Spring washer		
33	955781	X	Nut		
34	823409	1	Tachometer		
35	827149	1	Thermometer		
36	813864	1	Instrument		
37	844957	1	Hour counter		