



6631

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	846377	1	Actuator	
2	846426	1	Lever	
3	955637	1	Screw	
4	955857	1	Nut	
5	834551	1	Sender	
6	846717	1	Bushing	
7	846378	1	Control unit	
8	881532	1	Stop solenoid	
9	846422	1	Bracket	
10	846423	1	Pull link	
11	846424	1	Spacer sleeve	L = 64 MM
12	846425	1	Spacer sleeve	L = 30 MM
13	955542	1	Screw	
14	955536	1	Screw	
15	942336	2	Spring washer	
16	907824	1	Cotter pin	
17	955892	1	Washer	
18	955270	4	Screw	
19	955781	4	Nut	
20	941906	4	Spring washer	
21	881191	1	Cable union	
22	354671	1	Tachometer sensor	SEE GROUP 3
23	925059	1	O-ring	
24	846580	1	Angle contact	