


TMD41A, TAMD41A



TMD41A, TAMD41A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	860323	1	Conversion kit		
2	(859049)	1	• Cable trunk		Obsolete part
2A	966334	1	• • Fuse holder		
2B	11433	1	• • Fuse		For exhaust pressure regulator
3	966689	1	• Fuse		
4	837878	2	• Relay		
5	956074	1	• Cross recessed screw		
6	942605	1	• Toothed washer		
7	876175	1	• Control magnet kit		(859080)
8	862154	1	• Temperature sensor		
9	858229	1	• Thermo monitor		
10	957181	2	• Gasket		
11	838987	1	• Starter motor, starter motor components		
12	849563	1	• Alternator, generator components		For 24 voltage electric system., 28V 55A
	863955	1	• • Alternator		For 24 voltage electric system., Also available as an exchange part., 28V 60A
			Bulletin 45-02A	45-02A-EN	Alternator
13		1	• • Stop solenoid		(858058)
			Installation Instruction 7734977	7734977-EN	Stop Solenoid (MD 31, 41, 42)
14	948210	10	• • • Cable tie		
15	859063	1	• • • Instrument panel		Repl by 860141
	864041	1	• • • Instrument panel		
16	862155	1	• • • Oil pressure sensor		
17	858937	1	• • • Bracket		
18	838955	1	• • • Relay		
19	949278	1	• • • Flange lock nut		
20	965175	1	• • • Flange screw		
21	876132	1	• • • Glow plug		
22	859021	1	• • • • Glow plug		
22A	859328	1	• • • • Thrust sleeve		
23	965483	1	• • • • Flange nut		
24	941905	1	• • • • Spring washer		
25		1	• • • • o-ring		Not to be used where contact plate 860044 shall be used
26	859211	1	• • • • Sealing ring		
27		X	• • • cables and terminals		Alt see group 3
28	673580	X	• • • Adapter		
29	859451	1	• • • Rail		Glow plug 1-2, Alt
	859450	1	• • • Rail		Glow plug 2-3, Alt
	859449	1	• • • Rail		Glow plug 3-4, Alt
30	860044	1	• • • Switch brace		See group 3
31	243572	1	• • • O-ring		
32		2	screw		See group 2B
33		X	cables and terminals		See group 3