
26

4.3GiPEFS



4.3GiPEFS

REF PART NO. QTY DESCRIPTION 1 3852602 2 Hose clamp, Hose to thermostat housing 2 3853780 5 Hose clamp, Hose them hsg to exhaust manifold 3 3853391 1 Screw, Alignment bracket & thermostat hsg 4 3852649 1 Bracket, Alignment bracket 5 3853401 1 Screw, Thermostat hsg to engine 6 3850360 1 Housing, Thermostat hsg to manifold 7 3857843 2 Hose, Thermostat hsg to manifold	NOTES
2 3853780 5 Hose clamp, Hose them hsg to exhaust manifold 3 3853391 1 Screw, Alignment bracket & thermostat hsg 4 3852649 1 Bracket, Alignment bracket 5 3853401 1 Screw, Thermostat hsg to engine 6 3850360 1 Housing, Thermostat hsg 7 3857843 2 Hose, Thermostat hsg to manifold	
3 3853391 1 Screw, Alignment bracket & thermostat hsg 4 3852649 1 Bracket, Alignment bracket 5 3853401 1 Screw, Thermostat hsg to engine 6 3850360 1 Housing, Thermostat hsg 7 3857843 2 Hose, Thermostat hsg to manifold	
5 3853401 1 Screw, Thermostat hsg to engine 6 3850360 1 Housing, Thermostat hsg 7 3857843 2 Hose, Thermostat hsg to manifold	
6 3850360 1 Housing, Thermostat hsg 7 3857843 2 Hose, Thermostat hsg to manifold	
7 3857843 2 Hose, Thermostat hsg to manifold	
0 0050007 4 11 D 4-4-	Cut to length; port
8 3858237 1 Hose, Pump to thermostat hsg	
9 3858236 1 Hose, Cooler to pump	
10 3853786 2 Hose clamp, Hose, water pump inlet	
11 3852477 2 Gasket, Water pump to block	Part of engine gasket kit
12 980933 2 Washer	
13 3853850 1 Circulation pump	
14 3856147 2 Stud, Water pump	
15 3853390 4 Screw, Water pump pulley to hub	
16 3860083 1 Pulley, Water pump	
17 3856136 1 Bolt, Water pump, short 18 3857202 1 Sea water pump	
18 3857202 1 Sea water pump 19 3852071 1 O-ring, Thermostat	Part of engine gasket kit
20 3852071 1 O-ring, Thermostat 20 3852098 2 Hose clamp, Hose, thermostat hsg to water pump	Part of engine gasket kit
21 3856961 1 Thermostat, Engine	
22 3852111 1 Gasket, Thermostat hsg to engine	
23 3852288 1 Hose, Thermostat hsg to water pump	
24 3853598 1 Elbow, Thermostat hsg	Gi
25 3852507 1 Stud, P/S bracket, pump	O1
26 3858241 1 Stay, Stay, sea water pump	
27 3857954 1 Stop lug, Stay, sea water pump	
28 3853266 2 Screw, Stay bracket to engine	
29 3857939 3 Screw, Pump pulley to engine	