


4.3GLPLKD, 4.3GLPLKE, 4.3GSPLKD, 4.3GSPLKE, 4.3GSJLKD



12815

4.3GLPLKD, 4.3GLPLKE, 4.3GSPLKD, 4.3GSPLKE, 4.3GSJLKD

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3854620	1	Fuel pump	
2	3850820	2	O-ring, Fuel line to fuel pump, carburetor	
3	3853545	1	Fitting, Fuel line to fuel pump	
4	3852064	2	Nut, Circuit breaker terminals	Engine
	3852064	2	Nut, Circuit breaker terminals	Tilt & trim
5	3852001	2	Lock washer, Circuit breaker	
6	3854123	1	Fuel pipe, Fuel pump to carburetor	GS
	3855904	1	Tube, Fuel pump to carburetor	GL
7	3854238	1	Breaker, 6 amp, fuel pump	
8	3850403	1	Relay, Fuel pump	
9	3852481	11	Grommet	
10	3856438	1	Bracket, Fuel pump & relay mounting	
11	3853620	2	Screw, Circuit breaker to bracket	
12	3853311	2	Bracket	Stbd; front
13	3853557	1	Screw, Lift bracket & start leads to engine	
14	3853326	2	Screw, Lift bracket, fuel pump & relay assy	
15	3850861	1	Cover	
16	3851218	1	· Fuel filter	
17	3853266	2	Screw, Fuel pump, support bracket, fuel filter	
18	3852013	1	Elbow, Inlet, fuel filter cover	
19	3853310	1	Bracket, Fuel pump, support bracket & filter	
20	3852210	1	Bracket, Relay	
21	3852208	2	Screw, Relay & cable assy to support bracket	Electric fuel pump
22	3853493	1	Fitting, Fuel pump to fuel filter cover	
23	3850819	1	O-ring, Fitting	