



10401

500A,501A

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|---|----------|--|
| 1 | 855326 | 1 | Starter motor | | ALSO AVAILABLE AS AN EXCHANGE PART. |
| | | | | 030-0450 | |
| 2 | 835424 | 1 | Screw | | |
| 3 | 835425 | 1 | Screw | | |
| 4 | 942336 | 2 | Spring washer | | |
| 5 | 855315 | 1 | Anchorage | | |
| 6 | 940113 | 1 | Screw | | |
| 7 | 941907 | 1 | Spring washer | | |
| 8 | 941906 | 1 | Spring washer | | |
| 9 | 955825 | 1 | Nut | | |
| 9A | 841194 | X | Adjusting washer | | |
| 10 | | 1 | ALTERNATOR DRIVE BELT TEMPERATURE SENDER | 030-0188 | |
| 11 | 966857 | 1 | V-belt | | SEE GROUP 2B |
| 12 | 835630 | 1 | Temperature sensor | | SEE GROUP 2B |
| | 835649 | 1 | Sender | | FOR FLYING BRIDGE. |
| 13 | 856794 | 1 | Distributor | | (856699) |
| | | | | 030-0210 | |
| 14 | 835154 | 1 | Gasket | IK | |
| 15 | 841530 | 1 | Clamp | | |
| 16 | 855824 | 1 | Screw | | |
| 17 | 941744 | 1 | Washer | | |
| 18 | 948210 | X | Strip clamp | | |
| 19 | 856771 | X | Ignition cable | | L = 1000 MM. ALL IGNITION CABLES PARTNO 856771 WHICH ARE 1000MM AND SHOULD BE CUT OFF IN SUITABLE LENGTHS. |
| 20 | 856771 | X | Ignition cable | | L = 1000 MM. ALL IGNITION CABLES PARTNO 856771 WHICH ARE 1000MM AND SHOULD BE CUT OFF IN SUITABLE LENGTHS. |
| 21 | 876047 | 2 | Spark plug kit | | |
| 22 | 855706 | 1 | Ignition coil | | |
| 23 | 834772 | 2 | Nut | | |
| 24 | | 1 | BRACKET | | SEE GROUP 2D |
| 25 | 1219561 | 1 | Clamp | | |
| 26 | 834371 | 1 | Screw | | |
| 27 | 834784 | 1 | Resistor | | |
| 28 | 835429 | 2 | Retainer | | |
| 29 | 835428 | 2 | Retainer | | |
| 30 | 943629 | 3 | Screw | | (841426) |
| 31 | 835427 | 2 | Retainer | | |
| 32 | 835980 | 1 | Nipple | | |
| 33 | 809109 | 1 | Elbow nipple | | |
| 34 | 834920 | 1 | Oil pressure sensor | | |
| | 834921 | 1 | Oil pressure sensor | | FOR FLYING BRIDGE. |
| 35 | 841178 | 1 | Fuse | | 40A |
| 36 | 950013 | 2 | Screw | | |
| 37 | 856762 | 1 | Bracket | | |
| 37A | 965364 | 4 | Screw | | |
| 38 | 856727 | 1 | Cable trunk | | |
| 39 | | X | CABLE AND TERMINALS | 030-0625 | |
| 40 | 856881 | X | Extension cable | | L = 3000 MM |
| | 856882 | X | Extension cable | | L = 6000 MM |
| 41 | 856672 | 1 | Instrument panel | | USA, EARLY TYPE |
| | | | | 030-0560 | |
| | 856673 | 1 | Instrument panel | | EUR, EARLY TYPE |
| | | | | 030-0570 | |
| | 856820 | 1 | Instrument panel | | LATE TYPE |
| | | | | 030-0580 | |
| 42 | 942810 | 1 | Clamp | | |
| 43 | 955534 | 1 | Screw | | |
| 43A | 942336 | 1 | Spring washer | | |
| 44 | 943629 | 1 | Screw | | (841426) |
| 45 | 1585449 | 1 | Gasket | | |

7745640 - 030 - 030-0120

10401

Upd: 22 NOV 2005

500A, 501A

VOLVO
PENTA

