


7.4GLPNCA, 7.4GLPNCM, 7.4GIINCSCE, 7.4GIPNCACE, 7.4GIPNCMCE, 7.4GLINCS, 7.4GSIINCS, 7.4GSIXNCM



7.4GLPNCA, 7.4GLPNCM, 7.4GIINCSCE, 7.4GIPNCACE, 7.4GIPNCMCE, 7.4GLINCS, 7.4GSIINCS, 7.4GSIXNCM

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	3853353	1	Lock washer, Pulley		
2	3850211	2	Exhaust pipe, Upper		DP, DPX
	3853237	2	Exhaust pipe, Upper		SX, DP-S
3	3852742	2	Exhaust hose, Upper exhaust pipe to exhaust pipe		
4	3852604	8	Clamp, Hose, exhaust pipe		
5	3853401	1	Screw, Thermostat hsg to engine, short		
6	3852002	8	Lock washer, Exhaust elbov to manifold		
7	3852830	8	Screw, Elbov to exhaust manifold		
8	3850496	2	Gasket, Elbow to exhaust manifold		
			· Bulletin P-25-1-1	P-25-1-1-EN	Riser Gasket Replaced
9	3852362	2	Exhaust pipe, Port & stbd		
10	3852476	2	· Cap, Exhaust manifold		
11	3853326	8	Screw, Exhaust manifold		
12	3852602	2	Clamp, Cap to exhaust manifold		
13	3852220	1	Pulley, Water pump		
14	3852505	1	Pulley, Crankshaft, water pump		
15	3855778	1	Sea water pump		
16	3853354	1	Washer, Torsional damper		
17	3853502	1	Flange screw, Torsional damper		
18	3852696	2	Exhaust hose, Exhaust pipe upper to exhaust pipe		
19	3852507	1	Stud, Alternator brace to water pump, stbd		
20	3854653	4	Screw, Water pump		
21	3855472	4	Flange screw, Exhaust pipe to gimbal hsg		
22	3853404	8	Lock nut, Exhaust manifold to cyl head		
23	3853983	1	Thermostat, Engine		
			· Bulletin P-26-2-1	P-26-2-1-EN	Thermostat. 8.1L
24	3852140	8	Stud, Manifold to engine		
25	3852111	1	Gasket, Thermostat hsg to internal manifold		
26	3855991	1	Circulation pump		
27	3853361	2	Gasket, Water pump		
28	3852602	2	Clamp		
29	3852058	8	Washer		
30	3854383	1	Housing		GL
	3855018	1	Thermostat housing		Gi, 7.4 GSi; 8.2 GSi
31	3850999	1	Plug, Engine water pump, top		
32	3851000	1	Exhaust pipe		DP, DPX, Not shown
	3855281	1	Exhaust pipe		SX, DP-S
33		2	Seal, Exhaust pipe		
			· Bulletin P-25-1-2	P-25-1-2-EN	Exhaust Seal Obsolete
33		4	Bushing		
		1	Pin		
34	3850419	1	Hose, Engine cooler to thermostat		
35	3852098	1	Clamp		
36	3852098	1	Clamp		
37	3853241	1	Hose, Thermostat hsg to water pump		
38	3852602	3	Clamp, Hose		
39	3853390	4	Screw, Water pump pulley to hub		
40	3850430	1	V-belt		
41	3853392	3	Screw, Pulley to crankshaft		
42	3852071	1	O-ring, Thermostat		
43	3852597	2	Hose, Thermostat to manifold		
44	3852607	1	V-belt, Alternator		GL
	3854643	1	V-belt, Alternator		Gi, 7.4 GSi; 8.2 GSi
45	3853391	1	Screw, Lift bracket & thermostat hsg		
46	3853860	8	Clamp, Hose, exhaust pipe		
47	3852649	1	Bracket, Center lift		
48	3856444	2	Exhaust pipe, High rise, port & starboard		
49	3852472	2	Gasket, Manifold to engine		
50	3855594	1	Bracket, Water pump		
51	3850422	1	Clamp, Hose, water pump inlet		
52	3852602	1	Clamp, Hose, water pump outlet		
53	3850286	1	Hose, Sea water intake to water pump		GL
	3854852	1	Hose, Sea water intake to water pump		

7.4GLPNCA, 7.4GLPNCM, 7.4GIINCSCE, 7.4GIPNCACE, 7.4GIPNCMCE, 7.4GLINCS, 7.4GSIINCS, 7.4GSIXNCM

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
53		1	Hose, Sea water intake to water pump		
54	3850285	1	Hose, Water pump to P/S cooler		GL
	3854761	1	Hose, Water pump to reservoir		7.4 GSi
55	3853389	2	Screw, Water pump bracket to engine		7/16" - 14 UNC
	3853155	2	Screw, Water pump to bracket		3/8" - 16 UNC
56	3853397	2	Screw, Water pump to bracket		
57	3852162	2	Washer, Screw, water pump to bracket		