



994.4

**740A/MS5**

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	856609	1	Water pump · COMPONENTS		
2	856610	2	Gasket		
3	955536	4	Hexagon screw		
4	856611	1	Hose		
5		2	Hose attachment		
6	961666	4	Hose clamp		
7	855283	1	Pulley		
8	955656	4	Hexagon screw		
9	941907	4	Spring washer		
10	856513	1	Sea water pump		
				19972	
11	956594	3	Hex. socket screw		
12	942336	3	Spring washer		
13	856155	1	Bracket		
14	940116	2	Hexagon screw		
15	941909	2	Spring washer		
16	826422	1	Rubber bushing		
17	955523	1	Hexagon screw		
18	960141	1	Washer		
19	941907	1	Spring washer		
20	952077	1	Plug		INSTALLED ON THE INLET MANIFOLD.
21		1	THERMOSTAT HOUSING		
				19968	
22	835417	1	Gasket		
23	955538	2	Hexagon screw		
24	942336	2	Spring washer		
25		2	Coolant pipe		
26	855984	2	Coolant pipe	19967	
27	842913	4	Sealing ring		
28	858986	4	Sealing ring		
29	847108	2	Pipe retainer		
30	856452	2	Brace		
31	965175	2	Flange screw		
32	856529	1	Hose	19967	
33	943479	2	Hose clamp	19967	
34		1	HEAT EXCHANGER AND INSTALLATION COMPONENTS	19967	
35	856222	1	Coolant pipe		
36	952973	X	Hose		L = 2X70 MM
37	856268	1	Coolant pipe		
38	858587	1	Bracket		
39	940133	1	Hexagon screw		
40	942336	1	Spring washer		
41	943717	2	Clamp		
42	946544	2	Flange screw		
43	945407	2	Flange nut		
44	952973	X	Hose		L = 100 MM
45	952973	X	Hose		L = 1X100 MM
45A	856306	1	Hose	19967	
			Bulletin 42-14	42-14-EN	Hose
46	961669	18	Hose clamp		
47	855987	1	Coolant pipe		
48	855986	1	Coolant pipe		
49	952973	X	Hose		L = 100 MM
50	965175	8	Flange screw		
51		1	OIL COOLER		SEE GROUP 2A
52		1	CONNECTION		SEE GROUP 2A
53		1	Bracket		
54		1	Clamp		
55	946440	1	Flange screw		

740A/MS5

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
56	955526	2	Hexagon screw		
57		1	CONNECTION		SEE GROUP 2A
58	967191	1	V-belt, DRIVE BELT KIT		SEE GROUP 3 L = 2X1250 MM
59	856223	1	Coolant pipe		SEE GROUP 4A
60		1	Coolant pipe		SEE GROUP 4A
61		2	EXHAUST MANIFOLD	19970	