



8.1Gi-A, 8.1Gi-B, 8.1Gi-BF, 8.1GSi-A, 8.1GXi-A, 8.1GXi-AF, DPX375-A, DPX375-B, DPX375-BF, DPX420-A, DPX420-B, DPX420-BF, 8.1Giil-A, 8.1Giil-B, 8.1GSiil-A, 8.1GXiil-A



8.1Gi-A, 8.1Gi-B, 8.1Gi-BF, 8.1GSi-A, 8.1GXi-A, 8.1GXi-AF, DPX375-A, DPX375-B, DPX375-BF, DPX420-A, DPX420-B, DPX420-BF, 8.1Gii-A, 8.1Gii-B, 8.1GSii-A, 8.1GXii-A

| REF | PART NO. | QTY | DESCRIPTION     | SEE SEC. | NOTES    |
|-----|----------|-----|-----------------|----------|----------|
| 1   | 3860965  | 1   | Fuse box        |          |          |
| 2   | 3861373  | X   | · Fuse          |          | 15A      |
|     | 3861374  | X   | · Fuse          |          | 20A      |
| 3   | 3861376  | 2   | · Relay         |          |          |
| 4   | 3861375  | 1   | · Starter relay |          |          |
| 5   | 3860966  | 1   | Bracket         |          |          |
| 6   | 955234   | 4   | Screw           |          |          |
| 7   | 3860264  | 1   | Alarm           |          |          |
| 8   | 3861504  | 1   | Decal           |          | WARNING! |
| 9   | 3860531  | 2   | Screw           |          |          |
| 10  | 967949   | 1   | Screw           |          |          |
| 11  | 3854164  | 1   | Breaker         |          |          |
| 12  | 3852001  | 2   | Lock washer     |          |          |
| 13  | 3852064  | 2   | Nut             |          |          |
| 14  | 3853620  | 2   | Screw           |          |          |
| 15  |          | 1   | Wiring harness  | 5967     |          |
| 16  | 3852825  | 1   | Retainer        |          |          |
| 17  | 3852208  | 3   | Screw           |          |          |
| 18  | 3853786  | 1   | Clamp           |          |          |
| 19  | 3860853  | 1   | Bracket         |          |          |
| 20  | 946441   | 3   | Screw           |          |          |